

Operating manual | Inspection book

including spare parts list

Version: USA

Manual date: 13.01.2020

POWER LIFT HDL 15000 POWER LIFT HDL 18000

Serial No.



OPI-POWER LIFT HDL 15000 - HDL 18000-V1.0-EN





1	General informations5	4	Installation	37
1.1	Lift purpose5			
1.2	Liability5	5	Operating manual	37
1.3	Owner/Employer responsibilities5	5.1	Lifting the vehicle	
1.4	Lift operator responsibilities6	5.2	Lowering the vehicle	
1.5	Safety regulations6	5.3	Travel measurement	
1.6	Safety devices7	5.4	Manual equalization of the lifting rails	38
1.7	Safety labels affixed to lift8			
1.8	Protocols9	6	Behaviour in cases of error	41
1.9	Set up and test the lift9	6.1	Moving onto an obstacle	42
Setu	up protocol10	6.2	Emergency discharge of the lift	42
Tran	sfer protocol11	6.3	Reset after an emergency discharge	44
2	System master sheet12	7	Maintenance and care	44
2.1	Manufacturer12	7.1	Maintenance plan	45
2.2	Purpose	7.2	Cleaning the lift	
2.3	Changes to the design / construction		•	
2.4	Changing the assembly location12	8	Assembly and commissioning	50
		8.1	Set up guidelines	50
3	Technical information13	8.2	Commissioning	51
3.1	Technical data13	8.3	Changing the assembly location	51
3.2	Safety devices13			
3.3	Data sheets14	9	Safety inspection	56
3.4	Hydraulic plan / per lift column17	9.1	Single safety inspection before commissioning	57
3.5	Pneumatic plan18	9.2	Regular safety inspection and maintenance	58
3.6	Electrical circuit diagram19	9.3	Exceptional safety inspection	68

Spare parts list

1 General informations

Important safety instructions – Save these instructions

1.1 Lift purpose

Nussbaum lifting systems are the result of over 35 years' experience in the automotive lifting industry. The high quality and superior concept ensures reliability, a long Lift lifetime, and a strong economic business solution for your automotive lifting needs. The HDL 15000-18000 are a hydraulic asymmetric two-post Lift with a lifting capacity of 15000/18000 pounds. The Lift features a powerful integrated power unit and hard-chromed cylinders. The maximum load distribution is 15000 lbs (HDL 15000) / 18000 lbs (HDL18000) per arm.

1.2 Liability

To avoid unnecessary damage, injury or death, read all operating instructions carefully. Nussbaum is not liable for any damages, injuries, or deaths resulting from misuse of the Lift. The user carries the risk alone.

There will be no guarantee or liability for incidents involving injuries, death, or damage to equipment if these incidents are the result of one or more of the following:

- Inappropriate use of the Lift to include: Inappropriate installation, operation, and maintenance of the Lift.
- Use of the Lift while security devices are inoperative, not working properly, or are installed incorrectly.
- Failure to follow the operating instructions regarding transport, storage, installation, initiation, operation, and maintenance of the Lift.
- Unauthorized changes to the design and operation of the Lift.
- Wrong or incorrect maintenance practice.
- Catastrophes, acts of God, or external reasons.
- Nussbaum Lifts are warranted with the use of Nussbaum original or replacement parts. Use only replacement parts approved by the original equipment manufacturer or parts meeting original manufacturer specifications. Use of unauthorized parts may void the warranty. For parts, call Nussbaum at 1-704-864-2470.
- It should be recognized that any piece of equipment can be dangerous when operated improperly.

1.3 Owner/Employer responsibilities

Automotive lift institute safety requirements for operation, inspection and maintenance (ANSI/ALI ALOIM)

The Owner/Employer shall insure that lift operators are qualified and that they are trained in the safe use and operation of the lift: ALI SM10-1 safety manual; AL-ST-17; ANSI/ALOIM:2008 (R2013), American National Standard for Automotive Lifts-Safety Requirement for Operation, Inspection and Maintenance; ALI/WL Series, ALI Uniform Warning Label Decals/Placards; and in case of frame engaging lifts, ALI/LP-GUIDE, Vehicle Lifting Points/Quick Reference Guide for Frame Engaging Lifts and SAE J2184, Vehicle Lifting Points for Service Garage Lifting.

The Owner/Employer shall establish procedures to periodically inspect the lift in accordance with the lift manufacturer's instructions or ANSI/ALOIM:2008 (R2013), American National Standard for Automotive Lifts-Safety Requirements for Operation, Inspection and Maintenance; and the employer shall insure that the lift inspectors are qualified and that they are adequately trained in the inspection of the lift.

The Owner/Employer shall establish procedures to periodically maintain the lift in accordance with the lift manufacturer's instructions or ANSI/ALOIM:2008 (R2013), American National Standard for Automotive Lifts-Safety Requirements for Operation, Inspection and Maintenance; and the employer shall insure that the lift maintenance personnel are qualified and that they are adequately trained in the maintenance of the lift.

The Owner/Employer shall maintain the periodic inspection and maintenance records recommended by the manufacturer or ANSI/ALOIM:2008 (R2013), American National Standard for Automotive Lifts-Safety Requirements for Operation, Inspection and Maintenance.

The Owner/Employer shall display the lift manufacturer's operating instructions; ALI SM10-1 safety manual; AL-ST-17; ANSI/ALOIM:2008 (R2013), American National Standard for Automotive Lifts-Safety Requirement for Operation, Inspection and Maintenance; ALI/WL Series, ALI Uniform Warning Label Decals/Placards; and in case of frame engaging lifts, ALI/LP-GUIDE, Vehicle Lifting Points/Quick Reference Guide for Frame Engaging Lifts; in a conspicuous location in the lift area convenient to the operator.

Additional owner/employer responsibilities

- Shall require that Personal Protective Equipment (PPE) be used according to the appropriate regulations.
- Shall display the "Safety Regulations" and adhere to them closely.
- Shall ensure that all safety- and danger signs on and around the Lift are observed and followed!
- Shall follow the specified time intervals between the recommended inspection and maintenance procedures and tests.



- Shall use only spare parts that comply with the technical requirements specified by the manufacturer.
- Shall ensure that loose screws, nuts, and bolts are firmly tightened after maintenance.
- Shall not modify the Lift without written consent of Nussbaum.
- Shall ensure that these instructions are maintained and available to all personnel that install, use or maintain the lift. This document contains important information about installation, operation, and maintenance of the automotive Lift. Any changes to the installation and or location of the automotive Lift must be documented.

1.4 Lift operator responsibilities

- Shall read and understand all safety and warning instructions in the manual or affixed to the lift.
- Shall be trained to operate and use the HDL 15000-18000 Lift for its designed use.
- Shall be familiar with accident prevention and basic labor safety regulations.
- Shall not allow unauthorized personnel to operate the Lift.

Information of warning

Pay close attention to the danger and important information symbols shown below. Carefully read all marked passages throughout this manual.



Danger! This sign indicates danger to life. Improper handling of the described operation may cause serious injury or death.

- Caution! This sign warns against possible damage to the automotive Lift or other material defects in case of improper handling.
- Attention! This sign indicates an important function or note.

1.5 Safety regulations



The Safety Regulations must be observed and strictly adhered to while working with the automotive Lift. Read the safety regulations and the ANSI/ALI ALOIM manual included with the lift documentation carefully before working with the Lift!

Important safety instructions – read all instructions

- The total weight of the lifted vehicle must not exceed 15000 pounds (HDL 15000) / 18000 pounds (HDL 18000).
- The automotive Lift must be in its lowest position,

- and the Lift Carry Arms must be swung out before a vehicle can be driven into the Lift area.
- Total load must be distributed evenly on all arms.
- The Lift must not be installed in a hazardous location or in washing bays.
- The Lift must be checked by a service technician after initial installation and after repairs or changes have been made to the Lift.
- The operating and maintenance instructions must be followed while working with the Lift.
- Pre-check low clearance or specially equipped vehicles for ample clearance to avoid damage to the vehicle and/or Lift.
- Only trained personnel are to operate the Lift.
- No one is to stand within the working area (danger area) during vehicle lifting and lowering operations.
- No one is to occupy a vehicle during any phase of Lift operation.
- No one is to climb onto the automotive Lift when in a raised position.
- For unusual vehicles you may choose to instruct the user to contact Nussbaum for lifting advice.
- The main electrical switch must be switched off and locked out or tagged out according to OSHA Regulations before maintenance or repair work is performed on the Lift.
- The operator must continue to observe the vehicle and Lift throughout the lifting or lowering operation.
- Check the center of gravity of the vehicle if heavy parts, such as the engine are removed.
- If heavy parts such as the engine must be removed, the center of gravity will change. Secure the vehicle before removing parts to avoid the possibility of the vehicle becoming insecure.
- Read all instructions before operating lift.
- Care must be taken as burns may occur from touching hot parts.
- Do not operate the Lift with a damaged cord or if the Lift has been damaged – until it has been examined by a qualified service person.
- To reduce the risk of fire, do not operate Lift in the vicinity of open containers of flammable liquids (gasoline).
- Adequate ventilation should be provided when working on operating internal combustion engines.
- Keep hair, loose clothing, fingers, and all parts of body away from moving parts.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Always wear safety glasses. Everyday eyeglasses only have impact resistant lenses, they are not safety glasses.
- The proper positioning of the carrier plate below the vehicle is to be checked again after the vehicle has been raised slightly.
- After each set down of the vehicle, check the lift-



ing arm positions below the fixture points again and adjust as required.

- When disassembling heavy, consider any possible centre of mass shifts. The vehicle is to be appropriately secured using suitable materials (e.g. tensioning belts, beams, etc.) against falling.
- After design and maintenance on load bearing parts the lift must be inspected by a technical expert.
- Vehicles may only be attached at fixture points approved by the vehicle manufacturer.
- The entire lifting and lowering process is to be continuously observed.
- Initial access to the lift is only permitted after the main switch has been turned off and secured, and the operating lever is additionally secured against unauthorised use.

Save these instructions!

1.6 Safety devices

Nussbaum has designed several saftety features into each Lift to ensure safe and efficient operations under a variety of conditions. Warranties will be voided and dangerous working conditions exist if any of the listed devices are altered or disabled.

• Over-pressure valve

Hydraulic system fuse against over-pressure.

Check valve

Secure the vehicle against unauthorised lowerina.

• Main switch with curtain lock device Fuse to prevent unauthorised use.

Command / downstream system with latch
 Secure against unauthorised lowering of the lift.

• Deadman controls

Lift movement stops when the operating lever is released.

• Lifting arm block


Secures the lifting arm against horizontal movement in a lifted condition.



1.7 Safety labels affixed to lift

Warning Label pictographs used with permission of Automotive Lift Institute.







Read all labels and verify that all authorized users fully understand the meaning of each caution / warning / safety instruction. Do not remove or deface safety labels from the lift.

1.8 Protocols

Technical documentation contains important information for safe operation and for retaining functional safety of the lift.

- To verify lift set up, the assembly protocol form is to be completed, signed and sent to the manufacturer.
- Forms are available in this inspection book for use in verifying single, regular and extraordinary safety checks. Use the forms to document inspections and leave the completed forms in the inspection book.
- The lift master forms must record changes to the construction or changes to set up location.

1.9 Set up and test the lift

Safety relevant work on the lift and safety inspections may only be done by personnel specifically trained to carry it out. They are designated in general and in this documentation as technical experts and specialists (competent people).

- Technical experts are people (freelance expert engineers, TÜV specialists) that may inspect and assess due to their education and experience with lifts. They are knowledgeable in the appropriate work safety and accident prevention regulations.
- Specialists (competent people) are people who have sufficient knowledge and experience with lifts and have participated in a special factory training by the lifts manufacturer.



Set up protocol

After successful set up, complete this form fully, sign it, make a copy and send the original to the manufacturer within a week. The copy remains in the inspection book.

Nussbaum Automotive Solutions, LP 1932 Jordache Court Gastonia, NC 28052 Fax: 1-704-864-2476

Email: warranty@nussbaum-usa.com

The lift with serial number		was set up on (date)	
at (company name)		in (town, city)	
checked for function and sa	fety and put into operc	ation.	
The set up was done by the After successful inspection of trical connection (e.g. plug) the power supply is to be do	f function and safety by to on-site power supply	a trained assembler, the lity. An on-site electrical conn	ft is transferred without elec- nection between the lift and
The operating company con in this operating manual and at all times.			
The specialist confirms proper book, and has transferred th			ting manual and inspection
 Date	Name, operating company	and company stamp	Operating company signature
			-
Date	Name, specialist		Signature of specialist
Service partner:	Stamp		

*) See enclosed anchor manufacturer sheet



Transfer protocol

The lift with serial numb	er	was set up on (date)
at (company name) _		in (town, city)
checked for function o	and safety and put into o	peration.
	ople (operators) were trai er or a contract partner	ned to handle the lift after it was set up by a trained assem- specialist).
(Date, name, signature	e, empty lines must have	scored out)
 Date	 Name	Signature
 Date	 Name	Signature
Date	Name	Signature
 Date	Name	Signature
 Date	Name	
 Date	Name, specialist	Signature of specialist
Service partner:		



2 System master sheet

2.1 Manufacturer

Otto Nussbaum GmbH & Co. KG Korker Straße 24 D-77694 Kehl-Bodersweier

Name, address of technical expert

Location, date

2.2 Purpose

The lift is a lifting tool for raising vehicles up to a total weight of 15000 lbs (7000 kg) or 18000 lbs (8000 kg) for normal workshop operation.

The set up of the standard lift is not permitted in explosion endangered work shops and washing halls. The lift is not set up for moving people.

After construction and significant maintenance changes on load carrying parts the lift must be inspected afterwards by a specialist who approves the changes.

2.3 Changes to the design / construction Inspections by a technical expert are required before recommissioning (date, type of change, technical expert signature). Name, address of technical expert Location, date Technical expert signature 2.4 Changing the assembly location Inspections by a technical expert are required before recommissioning (date, type of change, specialist signature).

Signature of Technical Expert of Safety inspections



3 Technical information

3.1 Technical data

Load carrying capacity	HDL 15000 = 15000 lbs (6500 kg) HDL 18000 = 18000 lbs (8000 kg)
Loading a lifting arm	A single load from only one lifting arm may not happen
Lift / lowering time	approx. 70 sec. / 55 sec.
Standard operating voltage	1 ~/N+PE, 230 V, 60 Hz
Motor capacity	HDL 15000: 2x3 HP HDL 18000: 2x3 HP
Motor speed	3450 rpm
Operating pressure	HF 8000: 3900 psi
Pressure relief valve	HDL 15000: approx. 3600 psi HDL 18000: approx. 3700 psi
Oil volume	approx. 4,5 GAL
Noise level L _{PA}	≤70 dB
on-site connection	1 ~/N+PE, 230 V, 60 Hz with 16 Amp slow blow fuse according to VDI Regulations
Noise level LPA:	≤70 dB
on-site connection:	1~/N+PE, 230 V, 60 Hz with 16 A fuses, slow, ac- cording to US regulations

3.2 Safety devices

• Over-pressure valve

Hydraulic system fuse against over-pressure

Check valve

Secure the vehicle against unauthorised lowering

Lockable main switch

Fuse to prevent unauthorised use

Hydraulically unlockable safety system on the cylinders

Secure against unauthorised lowering of the lift.

• Up Off


Safety against a vehicle driving too widely onto the lift.

• Pneumatic lifting arm block


Safety against adjusting the lifting arm



3.3 Data sheets











Clearance around the lift






3.4 Hydraulic plan / per lift column



0.1	SPX 240	POWER UNIT	1.5 1.6	162406 161060	PRESSURE REDUCING VALVE PROPORTIONAL VALVE
1.0	99-540-11-00-5	BLOCK COMPLETE	1.7	99-540-60-11-5	THROTTLE ORIFICE
1.1	158502	2/2 WAY VALVE			
1.2	158503	2/2 WAY VALVE	2.1	265HDL2200	CYLINDER
1.3	155211	PRESSURE RELIEF VALVE	2.2		SST CYLINDER
1.4	130053	CHECK VALVE			



3.5 Pneumatic plan



0.2 960047 VALVE 1.0 265HDL28220 CYLINDER



3.6 Electrical circuit diagram

Grounding according to local regulations

Before commissioning check whether the nominal motor current matches the motor protection relay. Check all terminal points for proper connection and that all contact screws are tight.

Before commissioning, check all wiring and controls for proper function. Do not permit commissioning from the unauthorized side.

These plans were generated on a CAD system. To keep plans to the current state, we ask that you request Nußbaum to make the changes.

These circuit diagrams are intellectual property. They may not be given to third parties or reproduced without our permission!

Rights to make changes are retained.

Circuit diagram and switch documents

Circuit diagrams were made to the best of our knowledge.

No warranty for the correctness of provided circuit diagrams and switch documents is given. This is particularly relevant for switches that were completed by us according to third party plans. This was done by us from purchaser provided manufacturer documentation.

Functional test of switch systems

Circuit diagrams are not standard documents. When checking the control cabinet at the factory, field devices such as sensors, thermostats and motors cannot be included. For this reason, even with careful inspection, functional and switch errors cannot always be prevented.

Deficiencies are removed within the scope of guarantee during commissioning. During commissioning, if our services are not used, then no deficiency liability is accepted. Rework, including informing of circuit diagrams of switch systems not commissioned by us are therefore only done to an invoice according to our service terms and conditions. Costs for rework by third parties cannot be hounored.




	2 3	t	D D	7	ω	б
LSVerZelchni	TS	Spalte X:	Spalte X: eine automatisch erzeugte Seite wurde manuell nachbearbeitet Spitenzusatzfeld	manuell nachbearbeitet	WUPJOO5D 24.02.1994	02. 1994 X
Deckblatt		,	7 H H J N J - N J N J - N	25.01.2006	B0E	<
Inhaltsverzeichnis				25.01.2006	BOE	
Änderung				25.01.2006	BOE	
Einspeisung				25.01.2006	BOE	
Steuerspannung				25.01.2006	BOE	
Achscontroller				25.01.2006	BOE	
Ventile				25.01.2006	BOE	
Bedientasten				25.01.2006	BOE	
frei				25.01.2006	BOE	
X1				25.01.2006	BOE	
X1. 1				25.01.2006	BOE	
X2				25.01.2006	BOE	
X2. 1				25.01.2006	BOE	
Stückliste				25.01.2006	BOE	×
Stückliste				25.01.2006	BOE	×
						m
	Nussbaum Hebetec	Nussbaum Hebetechnik GmbH & Co. KG Korker Straße 24 D -77694 Kehl - Bodersweier	2. XX HDL SST 1 x 230V	_	п +	
Gepr. 04.09.19 Name Norm); + .	-0 Fax.:+49(0)7853/8787		Inhalt	Inhaltsverzeichnis	81. 2




																		+	E [8	
6																			81. 3	
		ORT/SEITE																	+	
80		ORT/																	Änderung	
7																			Ä	_
9																			1 × 230V	
				2016 enfällt Pneumatikventil Gegenseite															2. XX HDL SST	
2			fügt	ikventil (L		
t			otor einge	lt Pneumat														7	Tel.: +49(0)/853/8920 Fel.: +49(0)/853/8920 Frs.: -49(0)/853/8920	
			kte von Ma	016 enfäl.														4 c 4 c 4 c 4 c 4 c 4 c 4 c 4 c 4 c 4 c	1.: + 49(0)7853/899-	
m		Änderungen	Thermokontakte von Motor eingefügt	seit 03 / 2																
			Ī	Š.] []		
2	Z U	Bearbeiter	Вое	B o e														- 11		
	ÄNDERUNGS-INFORMATIONEN	Firma	NB	N B															Bearb. BOE Gepr. 04.09.19 Norm	
1	GS-INFO	wn:	25.01.2006	16.04.2015														+ 60	Bearb.	
0	ANDERUN	Nr. Datum	1 25.0	2 16.0															Anderuna	
																		7	A de	


























Änderung	Klemmenplan			WUPKM02D / 22.04.1996
Datum Name		Kabelname WM 2 WG 2 WM 1	Leistenbezeichnung X1	WH1. Kabelname
Datum 04,09.19 Bearb, UB1 Gepr. 04,09.19 Norm	Funktionstext	Kabeltyp Delflex Delflex Olflex	Rnschluß Ziel- bezeichnung Klemmen- Symbol Brücken Klemmen- nummer Anschluß Ziel- bezeichnung	Seite/Pfad Seite/Pfad Olflex Kabeltyp
Ur spr.	Einspeisung Kondensator	1	N 01 1 N 01 3 PE XM1 V V KM2 4	4. U 4. 1 9E 4. 1
SJOU	Unterölmotor 2	2 3	X1. 1 V V KM2 8 X1. 1 TH3 TH X1. 1 TH4 TH KM1 R1	4. 6 4. 7 4. 7
Nussbaum H Tel::+49(0)78	Proportional ventil 1 Sitzventil	PE	X1. 1 PE PE	4. 7 7. 3 7. 3
### Note: The Co. Ki	Halteventil Mutter Sitzventil Proportional ventil 2	1	YS1 R1 4 K2 11 YW1 R2 5 KM2 R2 X1.1 6 6 R1 030	7.4 7.3 7.6
2.	Sitzventil Halteventil Mutter Sitzventil	3 4 5	X1. 1 7 7	7. 7
XX HDL SST	Bediensäule Gegenseite	7 8	X1. 1 11 11	8. 4
1 × 230V	Not-Halt Gegenseite	9 10 11	X1. 1 14 14	5. 7
	Unterölmotor 1	13 3 4	X1. 1 18 18 A1 F28 XM1 19 A1 Z24 XM1 20 •	7.8
×				
+ 11				
11 81. 10 15 81.				ω



Änderung			10	Klemmenpla	η					1								2D / 23	2. 04. 1996	
Datum Name	В								Kabelname		Leis	stenbe X1	zeichn	nung		Kabelname	WG 2			c
Gepr. 04.09.19	. UB1	atum 04.09.19		Funktionstext					Kabeltyp	Ziel- bezeichnung	Anschluß	Klemmen-	Klemmen- Symbol Brücken	Ziel- bezeichnung	Anschluß	Kabeltyp	Oelflex Oelflex		Seite/Pfad	F
				Kondensator						XM2		U		X1	U		1		4. 6	
Ur spr.	<u> </u>	bracket		Unterölmotor 2						XM2		٧		X1	٧		2		4. 6	
				=						XM2		тнз		X1	TH		3		4. 7	
	L)			=						XM2		TH4		X1	TH		4		4. 7	
	<u>ارت</u>			=						XM2		PE		X1	PE		PE		4. 7	-
Ers. f.	25			Proportional ventil 2	\mathbb{H}			+	-	YP2		6		X1 X1	6 7		2	+	7.6	
: ((Sitzventil	\mathbb{H}	\square	\parallel	+	-	YP2	A 2	7		X1	8		3	\mathbb{H}	7.6	
				Halteventil Mutter	\mathbb{H}	\square	\parallel	$+\!\!+$	-	YS2 YW2		8		X1	9		4		7.7	
Te1.:+	Korker Straße 24 D =77694 Kehl = Bodersweier	2		Sitzventil						YS2	A2	10		X1	10		5		7. 7	
.49(0) 78	D -73	±		Bediensäule						54		11		X1	11		6		8.4	
)7853/899 Frs. d.	Korker 7694 Ke	D + D + D		Gegenseite					1	54	22	12		X1	12		7		8.5	
-0 Fax	Straß	50.1		=					1	\$5	44	13		X1	13		8		8. 5	4
166+	dersue			=						\$5	22	14		X1	14		9		8. 5	
0) 7853/	, e	20		Not-Halt Gegenseite						SN1	21	15		X1	15		10		5. 7	
8787		S .		=						SN1	22	16		X1	16		11		5. 7	
				Halteventil Mutter								17		X1	17		12		7.8	L
	2. XX			=								18		X1	18		13		7.8	
	X HDL																			
																				-
	SST								-											
	×								-											c
	2307								-											
	<								-											
									-											
									-									Ш		\
									1											
×1.									1											
									1											
																		+		٥
	+	п						\top									+	+		
																		\mathbb{H}		
	↓																	\blacksquare		u
B1.																				
15 Bl.			12														\coprod			



Änderung	11	Klemmenpla	an											WUPK	MOZD	/ 22.	04. 1996	
Datum Name						Kabelname		Leis	stenbe X	eze	eichn	ung	Kabelname					0
UB1 04. 09.	Datum 04.09.19	Funktionstext				Kabeltyp	Ziel- bezeichnung	Anschluß	Klemmen- nummer	Brücken	Klemmen- Symbol	Anschluß Ziel- bezeichnung	Kabeltyp				Seite/Pfad	Þ
Urspr.		Messgeber Säule 1					X2. 1 X2. 1	8	8			D14					6. 2	
		=					X2. 1 X2. 1	10 11	10 11			D18					6.3	2
Ers. f.		=					X2. 1	13	12			D22 D24					6.3	
				$\frac{1}{1}$			X2. 1	14	14			21					6.3	ω
Tel.::49(0)7853/899	ussbaum Hel																	
Tel.:+49(0)7853/899-0 Fax::+49(0)7853/8787	oetechnik G																	ŧ
4 9(0)7853/8787	mbH & □o. K0																	
																		υ ₁
Z. XX HDL SST																		
1 ×	•																	ō
230V	5																	
																		7
X 2																		
																		8
+	п																	
																		9
B1. 12 15 B1.	13																	



Änderung			12	Klemmenpla	n							1	WUPKM02D	/ 22.04.1996	5
Datum Name	13 D	B 0				Kabelname		Leis	xtenbe X2	zeichr	nung	Kabelname			0
Norm Ct.		Datum 04.09.19		Funktionstext		Kabeltyp	Ziel- bezeichnung	Anschluß	Klemmen-	Klemmen- Symbol Brücken	Anschluß Ziel- bezeichnung	Kabeltyp		Seite/Pfad	Þ
				Messgeber Säule 1			X5	1	8		X2 8			6. 2	
Urspr.		3		=			X5	2	9		X2 9			6.3	2
	(c			=			X5	3	10		X2 10			6.3	- 1
				=			X5	4	11		X2 12			6.3	- 1
		—)		=			X5	5 6	12		X2 13			6.3	1
Ers.f.		=-1		=			Schirm		14		X2 14			6.3	1
· · · (4	<u> </u>													- ω
	ᆫ	_													
	D 1.::+49[Nussbaum Hebetechnik GmbH & Co.KG] -
Ers. d.	-77694 0)7853/	Hebs										1			
	Kehl -	etechr -ker St										1			
	Fax.:+	nik G													
	19(0)78	⊪ H d €													
	53/8787	Го. <u>К</u>													1
		۵,										1			1
		2.										1			_ U
		2. XX HDL										1			
] -
		TSS													
		×										1			
		230V										1			
		<										1			
												}			
															1
												1			7
												1			1
X2. 1	5											1		\Box	1
⊢	١.														
														H	
														+	
	-	+ 11										1		\parallel	
															-
														+	
	B1.														وا
15			<u></u>											$\pm \parallel$	
B1.	<u>1</u> ω		14												



	Sti	Stückliste Bill of ma	aterials		NUSTÜCK1 17.01.2003	
Bauteilbenennung Component design.	Menge Amount	Bezeichnung Designation	Typen nummer Model number	Lieferant Supplier	Artikelnummer Article number	
B1	1	Hehscontroller RSC 2009 (RC3)	940262	Nussbaum	940262	
H1	1	chscontroll	PLATTENSTECK VERBIN 64P	Harting	996892	
R1	36	Federkontakt FC zum Crimpen (Einzelkontakte)	FEDERKONTAKT FC ZUM CRIMPEN	Harting	996891	
1 0		Biechhaiter HSL	120×10020	1.7.7.2	0350N103012	
# E	1 4	Befestigungssatz für Leiterkartenhalter	120X10059	Zubehör	C+0.755	
R1	2	4-poliger MICRO COMBICON Ttecker Phönix	FK-MC 0,5/4-ST-2,5	Phoenix Contact	994015	
R1	-	Hinterer Blechhalter für ASC			040UNI03064	
H1	1	3×13	653-9403		992676	
R1	1	Kunststoffschraube für ASC	984M3X006PA4		984M3X006PA4	
н3	₽	Display mit Flachbandleitung konfektioniert	DEM16481 SY-LY/L + LEITUNG	Nussbaum	175R6K03001	
H 6	.	Displayrahmen Klein , komplett	Z40TSRMZ1133	Nussbaum	240TSRM21133	
B1	-1 -		HDD-16MSGOBL 3-33ND1/3	Nussbaum	8 COODS 8 COOD	
1 -	4 =	۱ ۱	M4/8 SF		940061	
F1	. +	Feinsicherung 522.517		6.1F	9951863	
F 2	1	Sicherungsklemme Trenner 5*20 mm	M4/8. SF	Entrelec	990661	
F2	1	Feinsicherung 522.517	FEINSICHERUNG	GIF	9951863	
F3	1	Sicherungsklemme Trenner 5*20 mm	M4/8. SF	Entrelec	990661	
F3	1		FEINSICHERUNG	GIF	990286	
Ft		Sicherungsklemme Trenner 5*20 mm	M4/8. SF	Entrelec	990661	
† L	₽,		FEINSICHERUNG	GIF	990302	
T 7 2 R 1	-	Sicherungsklemme Irenner 5*20 mm	M4/8. SF	Entrelec	9990661	
n (C	H ==	Nichericank Jeese Trender D*20 es	M4/8 AF	T = 1 = 1	990661	
F. F.	4 4	Feinsicherung	FEINSICHERUNG	GIF	990124	
FM1	1	Sicherungsautomat 1 pol. 16 A Typ K	EP61 K16	General Elektric	992826	
FM2	1	Sicherungsautomat 1 pol. 16 A Typ K		General Elektric	992826	
FM3	1	Sicherungsautomat 1 pol. 16 A Typ K	K16	General Elektric	992826	
±₩4	1	16 A Typ K		General Elektric	992826	
61	1	Schalt-Netzgerät Achscontroller DC 24 V /2,5A	S60-F24 NICHT MEHR VERWENDEN	Pewatron	940101	
62(11)	€1	Trafo + Gleichrichter + Kondensator	TRAFO 1-PH	Schmelzer	990835	
HI	1	Digisond akustischer Signalgeber	B/P 228	Deltron Components	990331	
7.7	-1 ₹	Wech	14/77	B - K	990267	
1 2	⊣ -	INDUSTRIBLEDED OTS 200 0 HOCKSIE	1101/8	B I K	182038 0000284	
7. X	H ==	Industriere laissonke für q Werhsler	110178	T. B. C.	930207	
KM1	- =		T92 P7022-24	Tycon	99084221	
KM2	1	Leisungsrelais 24VDC	T92 P7D22-24	Tycon	99084221	
KT1	1	1,5 s	ZWEIDRAHT ZEITRELAIS	BTR	990212	
0.1	1	3p 40A ,11kW	1050	Merz GmbH	990375	
100	₽,	-		Moeller	990130	
SI SI		astenplatte Pfell (M22)	M22 - XU-S-X/	Moeller	990131 000085	
T S	2	Kontaktelement 15 [M22]	M22-K10	A	990133	
\$1	. 4	Kontaktelement 1Ö (M22)	M22-K01	Moeller	990181	
\$2	1	Drucktaste flach o. Tast. Platte (M22)	M22-D-X	Moeller	990130	
\$2	1	Tastenplatte Pfeil (M22)	M22-XD-S-X7	Moeller	990131	
5.2	1	Befestigungsadapter (M22)	M22-A	Moeller	990965	
5.2	2	Kontaktelement 1S (M22)	M22-K10	Moeller	990133	
13						15
Datum	m 04.09.19		2. XX HDL	SST 1 x 230V	п +	
0 0 0			rsweier +49(0)7853/8787		:	B1. 14
	Ī				1 1 1 1 1 1 1 1 1	



_ლ 1																											_														B1. 15	, r
NUSTÜCK1 17.01.2003	Artikelnummer Article number		990181	9901311	990965	990133	990130	990131	990300	990181	990130	990131	990965	990181	990366	990130	991045	990133	9950186	992387	990965	990181	940042	080600	118620	118620	118620	118620	118620	0.70.011									п	+	0 + 0 · · · · · · · · · · · · · · · · ·	ν -
	Lieferant Supplier	:	Moeller	Moeller	Moeller	Moeller	Moeller	Moeller	2	Moeller	Moeller	Moeller	x Moeller ∴ C	Moeller	OSER GmbH	Moeller	Moeller	Moeller	Moeller	Moeller	Moeller	Moeller	Kabel Wärhter GmbH & Co KG	Bosch GabH	Seehausen	Seehausen	Seehausen	Seehausen	Seenausen	רעע									£ 100	×		
materials	Typen nummer Model number		M22-K01	M22-XD-S-X12	M22-A	M22-K10	M22-D-X	M2Z-XD-S-X7	M22-H	M22-K01	M22-D-X	M22-X0-S-X7	M22-R	M22-K01	DS 131	M22-D-X	M22-XD-6-X1	M22-K10	M22-PV	M22-XYK	M22-A	M22-K01	BYV Z8 -1.00 PVF-STFIIFRI FITIING FI FX	GERÄTESTECKER	GERÄTESTECKER	GERÄTESTECKER	GERRTESTECKER	GERRTESTECKER	GERHIESTECKER	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0									nik GmbH & Co. KG	7. 7.	Fax.: +49(0)7853/8787	_
Stückliste Bill of n	Bezeichnung Designation	# 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	Kontaktelement 10 (M22) Drucktasta flack o Tast Plaats (M22)		Befestigungsadapter (M22)	ment 1S (M22)	ach o.	Tastenplatte Pfell (M22)	De-estrauniusanapre (=22) Kontaktelement 10 (=22)	Kontaktelement 1Ü (M22)	Drucktaste flach o. Tast. Platte (M22)	Tastenplatte Pfeil (M22)	Befestigungsadapter (M22) Kontabtolomont 18 (M22)	Kontaktelement 1Ö (M22)	Drucktaster Einbau klein 1S		Start (I)(M22)	Delestigungsanaprel (HZZ) Kontaktelement 1S (MZ2)	5	nterlegschild NOT – AUS gelb quadr.	Befestigungsadapter (M22)	Kontaktelement 1Ö (M22)	Sperrdiode BTV 28 -IUU IUUUV;3H Stenerleitung mit num Adern (1461 N)	in für Pneu	C182 9 N21 schwarz	Ventilstecker L182 9 NZ1 schwarz Ventilstecker L182 9 N21 schwarz	פורדדיריפניים רדסי ס מידי															
Stür	Menge Amount				1 E	1	1		1 6		1		- 1 c		1	1		2	1	1	1	-10		1 4	1	1	7 .	-		-									Datum 04.09.19	. B0E		
	Bauteilbenennung Component design.	4	\$2	S3	53	S3	hS	hs.	t 100	t S	SS	งภ	N 5 5 7 5 7 5 7 5 7 5 7 5 7 5 7 5 7 5 7	N C	26	5.7	57	57	SN1	SN1	SN1	SN1	T / T	Y L 1	YP1	YP2	YS1	482	1 W I	7 8 7								14	Datum	Bearb.	Верг.	



Pos	BMK	QTY.	DESIGNATION 1	ORDER ITEM NUMBER	MANUFACTURER	ITEM NUMBER	SCREEN. PATH
_	4	_	AXIS CONTROLLER ASC 2009 (AC3)	940262	NUSSBAUM	940262	6-1
7	[A	_	SPRING BAR 64-POLE FOR AXIS CONTROLLER	09 06 264 3201	HARTING	996892	6-1
က	٦	36	SPRING CONTACT FC FOR CRIMPING (SINGLE CONTACT)	09 06 000 8482	HARTING	996891	6-1
4	4	_	PANEL HOLDER ASC			035UNI03012	6-1
2	4	_	CIRCUIT BOARD HOLDER / CARD POCKET		ACCESSORIES	992045	6-1
9	4	_	FASTENING SET FOR CIRCUIT BOARD HOLDER		ACCESSORIES	992046	6-1
7	4	2	4-POLE MICRO COMBICON PLUG PHÖNIX	18 81 34 1	PHOENIX CONTACT	994015	6-1
8	F	_	REAR PANEL HOLDER FOR ASC			040UNI03064	6-1
6	۲	_	SPACER PCB M3X13 MM	653-9403		992676	1-9
0	F	_	PLASTIC SCREW FOR ASC	984M3X006PA4		984M3X006PA4	6-1
1	A3	_	DISPLAY FITTED WITH RIBBON CABLE	DEM16481 SY-LY/L + LINE	NUSSBAUM	175RGK03001	8-9
12	A3	_	DISPLAY FRAME, SMALL, COMPLETE	240TSRM21133	NUSSBAUM	240TSRM21133	8-9
13	19	_	HALL ELEMENT SWITCH HDD-16MS60BL.5-55ND1/5	HDD-16MS60BL,5-55ND1/5	NUSSBAUM	990658	1-9
4	B2	_	HALL ELEMENT SWITCH HDD-16MS60BL.5-55ND1/5	HDD-16MS60BL,5-55ND1/5	NUSSBAUM	990658	6-2
15	Ε	_	SAFETY CLAMP ISOLATOR 5*20 MM	0115657.25	ENTRELEC	199066	5-1
91	Ε	_	FINE FUSE 522.517	1A SLOW BLOW FUSE 5X20	GIF	9951863	5-1
17	F2	-	SAFETY CLAMP ISOLATOR 5*20 MM	0115657.25	ENTRELEC	990661	5-1
18	F2	-	FINE FUSE 522.517	1A SLOW BLOW FUSE 5X20	GIF	9951863	5-1
19	F3	_	SAFETY CLAMP ISOLATOR 5*20 MM	0115657.25	ENTRELEC	990661	5-1
20	F3	_	FINE FUSE	6.3A SLOW BLOW FUSE 5X20) GIF	990286	5-1
21	F4	_	SAFETY CLAMP ISOLATOR 5*20 MM	0115657.25	ENTRELEC	990661	5-3
22	F4	_	FINE FUSE	2A SLOW BLOW FUSE 5X20	GIF	990302	5-3
23	F5	_	SAFETY CLAMP ISOLATOR 5*20 MM	0115657.25	ENTRELEC	990661	5-3
24	F5	_	FINE FUSE	2A SLOW BLOW FUSE 5X20	GIF	990302	5-3
25	F6	_	SAFETY CLAMP ISOLATOR 5*20 MM	0115657.25	ENTRELEC	199066	5-3
26	F6	_	FINE FUSE	2.5A SLOW BLOW FUSE 5X20) GIF	990124	5-3
27	FM1	_	CIRCUIT BREAKER 3-POLE 25 A TYPE K	681643	GENERAL ELEKTRIC	992833	4-3
28	FM2	_	CIRCUIT BREAKER 3-POLE 25 A TYPE K	681643	GENERAL ELEKTRIC	992833	4-3
29	FM3	_	CIRCUIT BREAKER 3-POLE 25 A TYPE K	681643	GENERAL ELEKTRIC	992833	4-6



Pos	BMK	QTY.	DESIGNATION 1	ORDER ITEM NUMBER	MANUFACTURER	ITEM NUMBER	SCREEN. PATH
62	S 2	_	BUTTON PLATE ARROW (M22)	M22-XD-S-X7	MOELLER	990131	8-4
63	S 2	_	FASTENING ADAPTER (M22)	M22-A	MOELLER	596066	8-4
64	S 2	7	CONTACT ELEMENT 1S (M22)	M22-K10	MOELLER	990133	8-4
92	S 2	_	CONTACT ELEMENT 1Ö (M22)	M22-K01	MOELLER	990181	8-4
99	86	_	PUSH BUTTON INSERTION SMALL 1S	DS 131	OSER GMBH	990366	1-9
79	27	_	PUSH BUTTON FLAT OR BUTTON PLATE (M22)	M22-D-X	MOELLER	990130	8-8
89	27	_	START (I) (M22)	M22-XD-G-X1	MOELLER	991045	8-8
69	27	_	FASTENING ADAPTER (M22)	M22-A	MOELLER	990965	8-8
70	27	2	CONTACT ELEMENT 1S (M22)	M22-K10	MOELLER	990133	8-8
71	SNI	_	EMERGENCY STOP BUTTON RED (M22)	M22-PV	MOELLER	9950186	2-7
72	SN1	_	EMERGENCY STOPP UNDERLAY SIGN YELLOW SQUARE	M22-XYK	MOELLER	992387	5-7
73	SN1	_	FASTENING ADAPTER (M22)	M22-A	MOELLER	990965	2-7
74	SNI	_	CONTACT ELEMENT 1Ö (M22)	M22-K01	MOELLER	990181	2-7
75	>	_	BLOCKING DIODE BYV 28 -100 1000 V; 3 A		CONRAD ELEKTRONIK	940042	1-9
9/	WG2	_	CONTROL LINE WITH NUM. WIRES (14G1,0)	ÖPVC-JZ	KABEL WÄCHTER GMBH & CO.KG	991303	2-7
77	×	16	GROUNDING CLAMP	16518822	ENTRELEC	ENT.16518822	7-3
78	×	16	BLANK SIGN	23100007	ENTRELEC	ENT.23100007	7-3
79	X1.1	11	GROUNDING CLAMP	16518822	ENTRELEC	ENT.16518822	2-6
80	X1.1	11	BLANK SIGN	23100007	ENTRELEC	ENT.23100007	2-6
81	X 4	_	PLUG CONN. DEVICE PLUG KU. 6-POLE	172-8951	RS	990918	1-9
82	X 4	_	PLUG CONN, DEVICE PLUG KU, 6-POLE	172-9077	RS	990919	1-9
83	X 4	9	PIN INSERT FOR DEVICE PLUG	172-9140	SPÖRLE GMBH	991330	1-9
84	X 4	9	JACK INSERT FOR DEVICE PLUG	172-9134	SPÖRLE GMBH	991331	1-9
85	X5	_	PLUG CONN. DEVICE PLUG KU. 6-POLE	172-8951	RS	990918	6-2
98	X5	_	PLUG CONN. DEVICE PLUG KU. 6-POLE	172-9077	RS	990919	6-2
87	X5	9	PIN INSERT FOR DEVICE PLUG	172-9140	SPÖRLE GMBH	991330	6-2
88	X5	9	JACK INSERT FOR DEVICE PLUG	172-9134	SPÖRLE GMBH	991331	6-2
88	XM1	_	PLUG HOUSING 6-POLE KU	05 0-180906-0	AMP	990327	4-3
06	XMI	2	FLAT PLUG SLEEVE PLUG 6.3 MM	5.447.123.111	AMP	990328	4-3
16	XM1	2	CONTROL LINE WITH COLOUR WIRES (5G2,5)	ÖPVC-JZ	KABEL WÄCHTER GMBH & CO.KG	991435	4-3



Pos	BMK QTY.	QTY.	DESIGNATION 1	ORDER ITEM NUMBER	MANUFACTURER	ITEM NUMBER	SCREEN. Path
92	XM1	_	POWER CABLE 6000 MM	232SL03310	NUSSBAUM	232SL03310	4-3
93	XM2	_	PLUG HOUSING 6-POLE KU	05 0-180906-0	AMP	990327	4-6
94	XM2	2	FLAT PLUG SLEEVE PLUG 6.3 MM	5.447.123.111	AMP	990328	4-6
95	XM2	2	CONTROL LINE WITH COLOUR WIRES (5G2,5)	ÖPVC-JZ	KABEL WÄCHTER GMBH & CO.KG	991435	4-6
96	XM2	_	POWER CABLE 6000 MM	232SL03310	NUSSBAUM	232SL03310	4-6
26	YLI	_	VALVE PLUG BOSCH SMALL FOR PNEUMATICS	1834 484 051	воѕсн дмвн	009086	7-9
86	YP1	_	VALVE PLUG C182 9 N21 BLACK	KA132000B9 PG 9	SEEHAUSEN	118620	7-3
66	YP2	_	VALVE PLUG C182 9 N21 BLACK	KA132000B9 PG 9	SEEHAUSEN	118620	2-6
100	YS1	_	VALVE PLUG C182 9 N21 BLACK	KA132000B9 PG 9	SEEHAUSEN	118620	7-4
101	YS2	_	VALVE PLUG C182 9 N21 BLACK	KA132000B9 PG 9	SEEHAUSEN	118620	7-7
102	YWl	_	VALVE PLUG C182 9 N21 BLACK	KA132000B9 PG 9	SEEHAUSEN	118620	7-3
103	YW2	_	VALVE PLUG C182 9 N21 BLACK	KA132000B9 PG 9	SEEHAUSEN	118620	7-8



4 Installation

The installation of the Lift is performed by manufacturer trained technicians or by the manufacturer's distribution partner. The Lift owner may use their trained mechanics to install the Lift. The installation must be performed according to the following regulations:

- Use architectural plans, if available, to determine Lift location.
- Lift is intended for indoor installation only. Installation in an outdoor application is prohibited and will void the warranties of the product.
- Always consult a qualified person regarding local regulations for seismic requirements. The owner has

to consult a qualified person to address any local or state requirements (per the ALCTV standard: "a qualified person should be consulted to address any seismic loads and other local or state requirements")

- Do not install Lift in hazardous locations, pit or depression areas, or washing stalls.
- Concrete must have compression strength (see chapter 8).
- Mount on a foundation deeper than the local external frost line.
- Be sure to read the ANSI/ALI ALIS prior to installation.
- The installer has to return the instructional materials furnished with the lift back to the owner.

Shiping / parts list

POS	ITEM NAMES	ITEM CODES	QUANTITY	LOCATION
I	COLUMN MASTER WITH LIFTING CARRIAGE AND LIFTING ARMS		1	ВОХ
2	COLUMN SLAVE WITH LIFTING			
	CARRIAGE AND LIFTING ARMS		1	BOX
3	RISER	232SL05070	2	BOX
4	TRANSVERSE TUBE		1	BOX
5	COVER	265HDL01032	2	BOX
6	MEASURING HOSE 500 MM	982048	1	BOX
7	LOCKING PIN	250HDL48119	4	BOX
8	SCREW PACKAGE			PLASTIC BAG
	CYLINDER SCREWS M6 X 12		10	PLASTIC BAG
	NUT 6,4 - 9021ST ZN		10	PLASTIC BAG
9	MANUAL	975497	1	BOX

5 Operating manual



When handling the lift, it must absolutely comply with safety regulations. Carefully read the safety regulations in Section 4 before first operation!

5.1 Lifting the vehicle

- Drive the vehicle into the middle of the lift lengthwise.
- Secure the vehicle against rolling away. Apply the handbrake, put into gear.
- To swivel the lifting arm inwards, the "unlock" button must be pushed on the operating unit. This opens the pneumatic interlock.
 - Swing in the lifting arms and place the adjustable receiving plate at the vehicle manufacturer specified points. As soon as the lift is raised, the lifting arm is interlocked.
- Consider the total centre of mass, this must be as

close as possible to the middle of the lift.

Depending on the vehicle type, it may be required to raise the receiving plate so that the vehicle is horizontal in a raised state.




Figure 1

 Inspect the hazardous area. No person or object may stand in the working area of the lift, or on the lift.



- Switch on controls. Turn the main switch to position "1"
- Lift the vehicle until the wheels are off the ground. Push the "Lift" button.
- If the wheels are not blocked, interrupt the lifting process and check for proper seating of the carrier plate.



Ensure secure vehicle placement on the carrier plate, otherwise there is a danger of the vehicle dropping.

- Raise the vehicle to the desired working height.
- Always observe the complete lifting process.



Figure 2: Main operating elements

- A "Lift" button
- B "Lower" button
- D Optional balance buttons are possible
- E Button "Unlock the lifting arm"
- F Display



Bild 3: 2. operating element

- A "Lift" button
- B "Lower" button
- C Emergency stop button
- E Optional buttons on this operating element "Unlock the lifting arm"

5.2 Lowering the vehicle

 Inspect the hazardous area. No person or object may stand in the working area of the lift, or on the lift.

- Place the vehicle to the desired work position or lower it to the lowest position.
- Push the "Lower" button. The lift raises briefly (unlocking the safety cylinder) before the actual lowering process starts.
- Before reaching the lowest position the lift stops the lowering process for safety reasons (CE stop).
 - After a recheck of the hazardous area, push the "Lower" button again. During lowering to the lowest position an acoustic warning signal can be heard.
- The lowering process must be continuously observed.
- Once the lifting arms have reached the detectable lowest position, swivel the lifting arms outwards. For this, push the "unlock" button.
- The vehicle can be driven off the lift.

5.3 Travel measurement

- To measure the travel of the threaded spindle, a
 Hall sensor is attached to the hydraulic cylinders
 which counts the external ring in magnetised in crements. These increments are transmitted and
 compared on the computer control system (axis
 controller). An uneven lift rail is balanced to the
 same height during a lifting or lowering movement. The current height position of the lift can be
 read off from the display.
- The computer control system monitors the entire process of the lift during "lifting" and "lowering".
- The lift lowers during normal operation at 0.05 meters per second (HDL 6500: 0.039 meter per second)

If the speed increases, e.g. due to a defect in the hydraulic system, the computer control system detects this problem and removes hydraulic supply to the unlocking cylinders. The interactive safety system is activated and the lift remains in place.

5.4 Manual equalization of the lifting rails



Access to the DIP switch may solely be done by a trained and authorised specialist and only with the main switch turned off.


Once the Computer Control System detects a height difference of approx. 40 mm from one lift rail to another, the lift automatically sets down.



5.4.1 Axle controller ASC2010

Settings

Jumper settings





1	LED OUT 1	23	X1100 DISPLAY CONNECTOR
2	LED OUT 2	24	GREEN LED: CPU STATUS (FLASHES)
3	LED OUT 3	25	P1101 POTENTIOMETER CONTRAST DISPLAY
4	LED OUT 4	26	X501 ZERO JUMPER PIC
5	2 LED RED ENCODER AXIS 1	27	LED GREEN 5 V
6	2 LED RED ENCODER AXIS 2	28	LED GREEN 3.3 V
7	2 LED RED ENCODER AXIS 3	29	RED LED: IN 1
8	2 LED RED ENCODER AXIS 4	30	RED LED: IN 2
9	X603 X604 4 JUMPER FOR	31	RED LED: IN 3
	INTERFACES SWITCHOVER	32	RED LED: IN 4
10	X601 RS232- CONNECTOR	33	RED LED: IN 5
11	GREEN LED: USB RECEIVING	34	RED LED: IN 6
12	RED LED: USB TRANSMITTING	35	RED LED: IN 7
13	X600 USB TYPE B CONNECTOR	36	RED LED: IN 8
14	X602 2XCAN BUS CONNECTOR	37	GREEN LED: RELAY K500
15	JP600 CAN 1 TERMINATION	38	GREEN LED: RELAY K700
16	S1100 CPU RESET BUTTON	39	X901 64-PIN CONNECTOR STRIP
17	JP601 CAN 2 TERMINATION	40	K700 RELAY CPU MONITORING
18	GREEN LED: CAN STATUS	41	K500 RELAY PIC MONITORING
19	RED LED: CAN STATUS	42	LED PWM 1
20	JP1100 JUMPER FOR PROGRAMMING	43	LED PWM 2
21	S1101 DIP SWITCHES 1-8	44	LED PWM 3
22	X1101 CONNECTOR FOIL KEYBOARD	45	LED PWM 4

Designator: Ji	1	100
----------------	---	-----

Purpose	Programming mode See description Programming the µControllers
Open	Normal operation
Closed	Programming
Standard	Open

Designator: JP600

Purpose	Can BUS 1 See below under CAN- Bus
Open	No termination
Closed	120 Ω termination
Standard	Closed

Designator: X501

Purpose	Zero PIC See description PIC
Closed	Zeroing after switching on if opened within 2s
Standard	Open

Potentiometer P1101 contrast for LCD Display

The contrast for the LCD display can be adjusted with the P1101 potentiometer.

After changing a display this must be reset under certain circumstances, especially if the dis-play does not appear or there are black squares.

Reset \$1100 button

After activation of the \$1100 button the microprocessor performs a reset, i.e. the program restarts. This is similar to switching on the 24V supply voltage again.

DIP switch \$1101

The sliding switches 1 to 8 of the S1101 switch block can be switched off and on. The position on the side with the designation "ON" means that the switch is turned on.



The meaning of the switch is determined in the program, i.e. it has no application-specific functions.

Normal HB:

• Dip switch 5 – Automatic

Controlled operation (only for trained persons!):

- Dip-switches 1-4 (with 2 axes): Axis 1-4
- Dip-switch 7 "zero"

Program description of the PIC

Zeroing PIC

Manual:

A jumpered bridge over the push pin X501 Pin 1 and 2 while turning on the supply voltage and removing this bridge within the first 2 seconds after turning on the voltage carries out a ZE-ROING of the counter status.

The LED K500 must light up.

Only stick the push pin (jumper) for saving on **one** pin (→ bridge open)

6 Behaviour in cases of error

Defective operational readiness of the lift may be due to a simple error. Check the system for the listed sources of error.

If the error cannot be removed after an inspection to the named causes, then inform customer service or your dealer.



Independent repairs to the lift, especially on the safety devices, as well as inspections and repairs to electrical systems are prohibited. Work on electrical systems may only be done by electricians.

Problem: Motor does not start!

possible causes:	Repair:
no power supply	Check the power supply
The main switch is not switched on	Check the main switch
The main switch is defective	Check main switch
Defective fuse	Have fuses checked

Power supply interrupted	Inform customer service
Thermal fuse of the motor is active	Let the water cool
Lift rails are uneven by more than 40 mm	Manual equalisation see Section 5.3
Motor defective	Inform customer service

Problem: Motor starts, load is not lifted!

possible causes:	Repair:
The vehicle is too heavy	Unload vehicle
Hydraulic oil filling level is too low	Refill hydraulic oil
The emergency discharge screw is not closed	Check the emergency discharge screws
Hydraulic valve defective	Inform customer service
Mechanical pump defective	Inform customer service
Coupling defective	Inform customer service

Problem: The lift cannot be lowered!

possible causes:	Repair:
Lifting table is sitting on an obstacle	(see Section 6.1)
Hydraulic valve defective	Inform customer service
Defective fuse	Have fuses checked
Safety system does not unlock	Inform customer service
Incorrect push button actuated	



Problem: The lift arms cannot be swivelled in or out.

possible causes:	Repair:
The unlock switch is not pushed, or is defective	Have the button checked
No or insufficient compressed air available	Check air pressure
Compressed air line defective air flow noises	Check the path of the compressed air line. If required, inform customer service

6.1 Moving onto an obstacle

If the lift lowers onto an obstacle, the system automatically switches off, as soon as an unevenness of approx. ± 40 mm is detected.

6.1.1 Remove the obstacle



Access to the DIP switch may solely be done by a trained and authorised specialist and only with the main switch turned off.

- Remove the covers on the unit and the electrical box.
- Push the reset button 1 on the circuit board and hold it down. (See Figure 5)



Figure 5: Circuit board - axis controller

- Release the reset button.
- Set all DIP switches to the "off" position.
- Place the DIP switch 1 and 2 to the "on" position.



This process can only be done when the lift is not in the uppermost position.

Observe the vehicle and the reaction of the vehicle.

- Push the "▲" button until the obstacle can be removed.
- The lift rail that is higher must be lowered with the help of the dip switch, (see Section "5.4")



The lift rails first move to unlock upwards.

For large differences of the two lift rails it can be practical in some circumstances, to lift the lower lift rails.

- After balancing the lift rail a reset must be done as follows:
- Set all DIP switches to the "off" position.
- DIP switch 5 in the "on" position.
- Push the "▼" button until the lift (both lift rails) have reached the lowest position and the warning signal can no longer be heard.
- Push the DIP switch 7 to the "on" position.
- DIP switch 5 remains in the "on" position.
- Push the DIP switch 7 to the "off" position. LED K700 must light continuously.
- If necessary a reset of the pics must be done. (See Section 5.4 Axle controller – zeroing Pic)
- An additional light diode must flash every second.
- The lift must be raised and lowered several times without a vehicle while observing the entire lifting and lowering process.
- The covers must be replaced.

6.2 Emergency discharge of the lift



An emergency discharge is an access into the lift controls and may only be done by experienced specialists. The emergency discharge must be done in the following described sequence, otherwise it can lead to damage and hazard to life and limb.



Any kind of external leakage (defective hydraulic pipe) is not permitted and must immediately taken care of. This is absolutely necessary especially before an emergency discharge.

An emergency discharge can only be done by personnel who are trained to operate the lift.

Reason which make an emergency discharge necessary are for example, electrical blackout, for errors in the lowering valves, etc.

For a power outage or defective valves, there is the option of lowering the lift to the lowest position with some manual movements, so the vehicle can be moved from the lift.

Do an emergency discharge

- Switch off the main switch and secure against restart (shut down).
- Loosen and remove all unit covers.
- For safety reasons, block off the endangered area and the lift leaving ample room.
- Loosen and remove 2 counter nuts (spanner width 41) at the upper end of the lift rails in the direction of the arrow. This procedure must be done on all lift rails.



Figure 6

• The piston rods can jam in the upper bore of the lift rail when they are limited by any contamination deposits. To loosen these connections, we recommend a commercially available solvent and simultaneous lubricant (e.g. WD40). Spray this penetrating spray generously between the thread and bore. The treatment time depends on the degree of contamination.



Figure 7

 The cover of the mini-measurement connection and the tank cover must be loosened. Unscrew the corresponding mini-measurement hydraulic line approx. 500 mm long (available from your dealer) and guide into the tank.



Figure 8

• Screw on the long threaded sleeve (available from your dealer) and tighten clockwise using a suitable tool (spanner width 24) Lower the lift rails approx. 5-10 cm. Repeat the process on the next lift rails etc. The lift rails may only be lowered in steps of 5-10 cm until the entire lift has reached the lowest position.



Figure 9



Warning!! Only lower each column alternately by a max. of 5-10 cm otherwise there is a danger of falling.

- The entire emergency discharge must always be observed by the operator.
- The lift must be stopped until the defective parts are exchanged.



The lift may only be operated again once it has been returned to a seamless condition seen from a safety point of view.

Afterwards, do a reset as described in the operating manual.



6.3 Reset after an emergency discharge

A reset may only be done once the lift is in its lowest position.



Access to the DIP switch may only be done by a trained, authorised specialist.

- a) There may not be any vehicles on the lift.
- b) Remove the rear column covers on the operating column.
- c) Loosen and remove the electrical box cover.
- d) Push button 1 (reset button) and hold it down.
- e) Switch off the main switch and wait 5 seconds (hold the reset button down).
- f) Switch on the main switch and wait 5 seconds. (Hold down the reset button).
- g) Release the reset button.
- h) Push the "Lower" button until the lift (both platforms) have reached the lowest position.
- i) If required, repeat steps d) to h) to be sure that the lift has reached the lowest position.
- j) Afterwards, place the DIP switch 7 to the "on" position.
- k) DIP switch 5 remains in the "on" position.
- I) Repeat steps d) to h).
- m) Afterwards, place the DIP switch 7 to the "off" position. DIP switch 5 remains in the "on" position.
- n) Only 3 light diodes are permanently lit on the circuit board. An additional light diode must flash every second.
- The lift must be raised and lowered several times without a vehicle while observing the entire lifting and lowering process.
- p) The covers must be replaced.

7 Maintenance and care

Before maintenance, do all preparation work so there is no danger to life or limb or object damage during maintenance and repair work.

To guarantee the largest possible availability and functional capacity of the system, ensure the list of any cleaning, care and maintenance work is done. The system is to be serviced at regular intervals according to the following plan. For intensive operation and higher degree of contamination shorten the service interval.

The complete function of the system is to be observed during daily use. Customer service must be informed of any malfunctions or leaks.



7.1 Maintenance plan

Before beginning service, disconnect from power. The work area around the lift is to be secured against unauthorised use.

		₹		TE.	MIL	
Visual inspection	Spray	Oil	Lubricate	Clean with compressed air	Clean	Inspect

Ti	Time frame Position Type of maintenance		Person in charge	Maintenance plan
As required			Lift owner / employer	The lift cylinder can sweat and small oil droplets can form on the base plate, this is however, not a leak.
Daily	9 365 x / 12 3 8 7 6 5		Lift owner / employer	Model and information signs, labels, brief operating instructions, safety stickers and warning information are to be cleaned and exchanged if damaged.
Daily	9 365 x / 12 3 8 7 6 5		Lift owner / employer	Check the foot bumper for condition and function. Exchange if damaged.
Daily	9 365 x / 12 3 8 7 6 5		Lift owner / employer	The rubber acceptance plate is to be checked for wear and replaced if necessary.
Every 3 months	9 4 x / 12 3 8 7 6 5		Lift owner / employer	Check the tracks and the lift rail equalization parts for wear. After cleaning, grease with multi-purpose grease. We exclusively recommend that MO-2 high performance lubricating grease is used. (available for purchase directly from Oest).
Annually	9 1 x / 12 3 8 7 6 5		Trained ser- vice personnel	Check the lifting arm block and gear for wear. Exchange if there is visible damage.



Time frame Position Person in Type of charge maintenance				Maintenance plan		
Annually	9 1 x / 12 3 8 7 6 5		Trained ser- vice personnel	Lifting arm booms, lifting arm bolts, carrier plate threaded bolts are to be checked for ease of running. If required, lightly grease with multi-purpose grease. Do not over-lubricate.		
Every 3 months	11 12 1 9 4 x / 12 3 8 7 6 5		Lift owner / employer	Version with MINI-MAX lifting arm 1. Blow out and spray bolts. Check the rollers for wear. 2. Check the locking screws (this is only screwed in lightly and is then glued (Loctite)). Screws may not be completely tightened otherwise the ease of running of the Mini-Max mechanism is no longer guaranteed. 3. Clean and spray this frictional surface. "Penetrating oil" similar to Top 2000 from Autol. 4. Check the safety plate for damage and exchange if required.		
Annually	9 1 x / 12 3 8 7 6 5		Trained ser- vice personnel	Check all fastening screws and anchors with a torque wrench. Fastening class 8.8 0.08* 0.12** 0.14*** M8 17.9 23.1 25.3 M10 36 46 51 M12 61 80 87 M16 147 194 214 M20 297 391 430 M24 512 675 743 Fastening class 10.9 0.08* 0.12** 0.14*** M8 26.2 34 37.2 M10 53 68 75 M12 90 117 128 M16 216 285 314 M20 423 557 615 M24 730 960 1060 * Lubricated slide friction number 0.12 *** Ensured slide friction number 0.14 screw with micro-encap-sulated plastic		



T	ime frame	Position Type of maintenance	Person in charge	Maintenance plan
Annually	9 1 x / 12 3 8 7 6 5		Trained ser- vice personnel	All weld seams must have a visual inspection. Stop the system and contact the manufacturer if there are cracks or breaks in weld seams of the lift.
Annually	9 1 x / 12 3 8 7 6 5		Trained ser- vice personnel	Check electrical components for function and condition. • Plug. • Operating lever with button switch. • During assembly and maintenance always check the condition of electrical lines. All cables and lines must be secured so they cannot be crushed, kinked or contact any moving assembly.
Annually	9 1 x / 12 3 8 7 6 5		Trained ser- vice personnel	Optional energy set: • Electrical socket • Pneumatic connection Check for condition and function.
Annually	9 1 x / 12 3 8 7 6 5		Trained ser- vice personnel	 Check the paint: Check the powder coating and improve if required. Damage by external influences is to be treated immediately after detection. If these points are not treated, infiltration of deposits of all kinds can cause wide-ranging and permanent damage. These points are to be lightly sanded (120 grit), cleaned and degreased. Afterwards, rework with a suitable touch up paint (note the RAL No.). Check galvanised surfaces, touch up as needed. White rust is fostered by permanent humidity, poor ventilation. The affected areas can be treated by using a sanding cloth (A 280 grit). If required, the parts are to be treated with a suitable, resistant material (paint etc.). Check the RAL colour selection. Rust is brought out by mechanical damage, wear, aggressive deposits (de-icing salt, leaking operating fluids) cleaning that is not done or incomplete. The affected areas can be treated by using a sanding cloth (A 280 grit). If required, post-treat the areas with a resistant material (paint etc.).



Ti	ime frame	Position Type of maintenance	Person in charge	Maintenance plan
Annually	9 1 x / 12 3 8 7 6 5		Trained service personnel	According to manufacturer instructions, the hydraulic oil should be changed every two years in normal operations. Various environmental influences e.g. location, temperature swings, intensive operation etc, can have an influence on the quality of the hydraulic oil. For this reason, the oil must be checked during annual safety inspections and maintenance. The oil is used if it has a milky colour or if the hydraulic oil smells unpleasantly. To change oil, lower the lift is to its lowest position then suction the oil out of the oil container and replace the contents. The manufacturer recommends high-quality clean hydraulic oil. The required oil volume and type is to be taken from the technical data. After filling (18), the hydraulic oil must be between the upper and lower marking on the oil dipstick, or approx. 2 cm below the oil filling opening. Dispose of the old oil according to regulations to the intended location (district offices, environmental protection office or commercial regulatory office has the obligation to disclose about disposal points).



Ti	ime frame	Position Type of maintenance	Person in charge	Maintenance plan
Annually	$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$		Trained ser- vice personnel	Storage and duration of use Excerpt from DIN20066:2002-10 • For permitted loading, hoses undergo a natural change. This limits the duration of use. • Improper storage, mechanical damage and unpermitted loads are the most frequent cause of breakdowns. • The duration of use of a hose line including any storage time should not exceed six years. Hose lines are to be replaced if/when, • Damage to the outer coating up to the insert (chafe marks, cuts, cracks). • The outer coating becomes brittle (crack formation). • Deformation from the natural shape in the depressurised and pressurised conditions. • Leakage. • Damage or deformation of the mounting fixture. • Meandering of the mounting fixture. • The lifetime has been exceeded. Repair of the hose line using the implemented hose / mounting fixture is not permitted. Extending the replacement intervals given in the guideline is possible if the inspection for safe-work condition is done in adjusted, shortened time frames, if required and by competent personnel. If there is an extension of the replacement interval, no situation may occur which could result in injury of employees or other personnel.
Annually	$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$		Trained service personnel	Excerpt from BGR237: Specifications for the hydraulic hose lines. Normal specification: Recommended exchange intervals: 6 years (operation duration including max. 2 years storage time). Increased demands e.g. by • Increased usage times e.g. multi-shift, short cycle times and pressure impulses. • Increased exterior and interior (due to media) influences which significantly reduce the lifetime of the hose lines. Recommended exchange intervals: 6 years (operation duration including max. 2 years storage time).



7.2 Cleaning the lift

A regular and expert clean helps retain the value of the lift.

Additionally, it can also be a pre-requisite for the preservation of guarantee claims for any eventual corrosion damage.

The best protection for the lift is regular removal of contaminants of any kind.

This includes above all:

- De-icing salt
- Sand, pebbles, earth
- Industrial dust of all types
- Water, also in connection with other environmental influences
- Aggressive deposits of all types
- Permanent humidity due to insufficient ventilation

The frequency of lift cleaning depends, among other things on the frequency of use, of lift handling, of workshop cleanliness, and the location of the lift. Furthermore, the degree of contamination depends on the time of year, the weather conditions and workshop ventilation. Under adverse circumstances, weekly lift cleaning might be required, however a monthly cleaning may be sufficient.

Do not use and aggressive and abrasive materials for cleaning, rather use mild cleaners, e.g. a commercially available detergent and lukewarm water.

- For cleaning, do **not** use high pressure washers (e.g. steam cleaners).
- Carefully remove all contamination with a sponge, or if required with a brush.
- Make sure that there is no residue of the cleaner on the lift.
- Rub the lift dry with a cloth after cleaning.

8 Assembly and commissioning

8.1 Set up guidelines

- Lift set up is done by trained manufacturer personnel or a contract partner. If the operating company has appropriately trained assemblers, the lift can also be set up by them. Set up is to be done according to the assembly instructions.
- A standard lift may not be set up in explosion endangered spaces or wash halls. (It is necessary to consult with your dealer).
- Before setting up, verify that there is a sufficient foundation or make it according to the guidelines in the foundation plan. The set up location must be level and even. Foundations in open air and spaces where winter storms or frost are to be expected, must have a foundation to frost depth.
- An on-site electrical connection of 1 \sim /N + PE, 230V, 60Hz is to be provided. The supply is to be

- secured on-site with 16 ampere fuses. The connection point is located on the operating boxes.
- To protect the electrical cable all cable conduits are to be fitted with cable sleeves or flexible plastic pipes.

8.1.1 Set up and anchoring the lift

- Before setting up the lift, ensure that everything possible is done to prevent accidents due to careless assembly. This includes, above all, the use of safe auxiliary means (e.g. cranes, forklifts and a sufficient number of people), diverse supports and a sufficient barrier to prevent unauthorised access.
- Carefully remove the lift from the wooden crate and check for damage.
- Position and align the lift columns according to the data sheet at the desired set up location.
- Guide the supply line to the operating column (on-site).
- Connect the electrical cables and measurement cables to both columns.
- Check the position of the lift again.
- Fill with approx. 17 litres of clean hydraulic oil into the oil container of the unit.
- Holes for floor anchorings are to be placed through the holes in the base plates. Clean the bore holes by blowing them out with air. Guide the safety anchor into the drilled holes but do not fasten them yet.
 - The lift manufacturer recommends Liebig safety anchors or similar anchors from other reputable anchor manufacturers Hilti, Fischer (with approval) while following their conditions. Information can be given from your anchor suppliers.
- Before anchoring the lift, check whether the load-bearing concrete is of quality min. C20/25 up to the finishing level of the completed floor. In this case, take the anchor length from "anchor length without floor covering". If there is a floor covering (tiles, screed) on the load carrying concrete, the thickness of this covering must be determined and the anchor length selected according to "anchor length with floor covering".
- Briefly push the "Lift" button. Consider the rotation direction of the motor.
- If the lift rail does not lift, the rotation direction of the motor must be checked again and if required two phases of the power supply must be exchanged. (only for 3-phase AC supply).
- Check the precise vertical set up of the lift columns and if required make sure there is a suitable support (panel strips) that make contact with the floor

To prevent vertical oscillations of the column, it is necessary to position the support in the middle and not only on the edge of the base plate.



- Tighten the anchor to the required torque (see the conditions of the anchor manufacturer).
- Each anchor must be tightened to the required torque. Safe operation and stability of the lift are not guaranteed with a lower torque.
- If required, do a reset before first operation. (see Section 6.3).
- Raise the lift approx. 800 mm.
- Mount the lifting arm. Secure the bolts with the locking rings.
- The lift must be moved to the "lift" and "lower" end positions without a vehicle.
- The safety devices must be checked.
- Move the lift with the load into the end position several times. (see Section 5.1).
- Check the hydraulic lines again for leak-tightness.
- Check the anchor fastenings again.
- In case of malfunction, firstly inform customer service.

8.2 Commissioning

Before commissioning, a single safety inspection must be done (use the "single safety inspection" form)

If the lift set up is done by a specialist (factory trained assembler) then he can also do the safety inspection. If the set up is done by the operating company then a specialist must be tasked with the safety inspection. The specialist confirms seamless operation of the lift on the set up protocol for single safety inspection and releases the lift for use.

After commissioning, the set up protocol must be completed and sent to the manufacturer.

8.3 Changing the assembly location


To change the assembly location the pre-conditions must be met according to the assembly guidelines. The location change is to be done according to the following sequence.

- Move the lifting stage upwards to approx. 1,000 mm.
- Remove the tank covers
- Remove the lifting arm.
- Lower the lift to the lowest position.
- Disconnect power.
- Loosen base plate anchors.
- Transport the lift to the new assembly location.
- Assemble the lift according to the procedure during assembly and anchoring before first commissioning.
- Use new anchors. The old anchors are no longer fit for purpose!

Before re-commissioning, a safety inspection must be done by a specialist (use the regular safety inspection form)



8.3.1 Selection the Liebig anchor without floor cover (2.65 HDL SST, 2.70 HDL SST, 2.80 HDL SST)



Liebig anchor

Anchor type BM16-25/100/40

Drill depth (mm)a125Min. anchoring depth (mm)b100Concrete thickness (mm)cmin. 200*Drill diameter (mm)d25Drilled part thickness (mm)e0-40

Concrete quality Min.C20/25 (B25) normal reinforcement¹

Number of anchors (pc.) Depending on the lift type

Torque of the anchors 115 Nm

(*) Min. concrete thickness when using the above-mentioned anchor, otherwise follow the details in the foundation plans.


Similar value anchors and other known brands of anchor manufacturers can be used when considering the conditions.

(1) Description of normal reinforcement:

A normal reinforcement is present if the axis separation in the area of the anchor with a rod diameter of \geq 10 mm is 150 mm, or for a rod diameter of \leq 10 mm is 100 mm.



8.3.2 Selection the Liebig anchor with floor cover (2.65 HDL SST, 2.70 HDL SST, 2.80 HDL SST)



Liebig anchor

Anchor type		BM16-25/100/65	BM16-25/100/100
Drill depth (mm)	а	125	125
Min. anchoring depth (mm)	b	100	100
Concrete thickness (mm)	С	min. 200*	min. 200*
Drill diameter (mm)	d	25	25
Component thickness (mm) e	+f	40-65	65-100
Concrete quality		Min.C20/25 normal rein	nforcement ¹
Number of anchors (pc.)		depending on the lift ty	уре
Torque of the anchors		115 Nm	115 Nm

(*) Min. concrete thickness when using the above-mentioned anchor, otherwise follow the details in the foundation plans.


Similar value anchors and other known brands of anchor manufacturers can be used when considering the conditions.


(1) Description of normal reinforcement:

A normal reinforcement is present if the axis separation in the area of the anchor with a rod diameter of \geq 10 mm is 150 mm, or for a rod diameter of \leq 10 mm is 100 mm.



8.3.3 Fischer anchor






subject to alterations!

fischer anchor		2.65 HDL SST 2.70 HDL SST 2.80 HDL SST
typ of dowel		FH 24/100 B Order No. 970267
drilling depth (mm)	† _d	255
min.anchorage depth (mm)	hef	125
thickness of concrete (mm)	С	see current founda- tion-diagram draw- ing
diameter of bore (mm)	d₀	24
thickness of the lift-piece (mm)	† _{fix}	0-100
turníng moment (Nm)	Mo	120
Total length (mm)	ı	272
Thread	М	M16
piece number	а	4
	b	8
	С	10
	d	12
	е	16
	f	20
	g	14

It is possible to use equivalent safety-dowels (with license) of other manufacturer but observe their regulations.



8.3.4 Hilti injection anchor (2.65 HDL SST, 2.70 HDL SST, 2.80 HDL SST)



subject to alterations!

Adhesive and anchor rod: HIT-HY 200-A + HIT-V (5.8) M16
Art. Hilti: 387066 HIT-V-5.8 M16x300 / 2022696

Seismic / filling set or suitable filling method

Effective anchoring depth: $h_{ef} = 190.0 \text{ mm}$

Material: 5.8

Registration number: ETA 11/0493 Issued / valid: 2/3/2017 | -

Anchor plate: lx x ly x t = 850.0 mm x 525.0 mm x 30.0 mm

Ground: Cracked concrete, C20/25, fc,cube = 25,00 N/mm2; h = 226,0 mm,

Temp.: 24 °C (max. 40 °C)

Installation: Drilled hole: hammer-drilled, dry

Reinforcement: No reinforcement or rod spacing \geq 150 mm (each diameter) or \geq 100

mm (diameter ≤ 10mm)

No edge length reinforcement

Reinforcement is provided to prevent cracks according to EOTA TR

029, 5.2.2.6.

Observe necessarily the installation description of the dowel manufacturer. Use longer dowels with version with floor pavement and tiles.

It is possible to use equivalent injections dowels (with license) of other manufacturer but observe their regulations.



9 Safety inspection

The safety inspection is required to guarantee operational safety of the lift. It is to be done:

- 1. before first commissioning after setting up the lift Use the "single safety inspection" form
- After first commissioning, check regularly at least once per year.
 Use the "regular safety inspection" form
- 3. After changes to the lift construction.

 Use the "extraordinary safety inspection" form
- Single and regular safety inspections must be done by a specialist. It is recommended to do maintenance at the same time.
- After a change in construction (for example changing the load carrying capacity or changing the lifting height) and after significant maintenance on load carrying parts (e.g. welding work), inspection by a technical expert is required (extraordinary safety inspection).

This inspection book contains forms for copying to be used for safety inspections.

Please use the appropriate form, record the condition of the inspected lift and leave the completed form in this inspection book.



9.1 Single safety inspection before commissioning

Test step	OK	Defect Missing		Remarks
General condition of lift	🗆	П		
Model plate				
Quick operating manual				
Warning label	Π		<u> </u>	
Condition button "▲/▼" + Main sv	witch \Box			
Condition of the "Balance" "Unloc	rk" huttons □		🗀	
Condition / function display				
Condition of the "Balance" "Unloc Condition / function display Operating boxes condition Bridging switch function	□			
Bridging switch function	□			
Condition / function lifting arm blo	□			
Condition / function lifting arm blo Interac. function Safety system Function ease of travel of the lifting	'Ск			
Eupotion ages of travel of the lifting	□			
Condition of the lifting arm / elector	g all II or overlay			
Carrier plate fue	iei oveilay 🗆			
Condition of the lifting arm / elaston Carrier plate fuse Securing the bolts				
Securing the bolls	🗀			
Condition of bolts and bearing sec	aiing ⊔		닏	
Condition of weld seams	∐	📙		
Load bearing construction (deformation	ons, cracks) 📙	∐	∐	
Fastening screw forque		∐		
Load bearing construction (deformation for the fastening screw torque for the fastening anchor torque for the fastening		∐	∐	
Linit condition			1 1	
Piston rods surface condition Condition of covers	🗆	🗆	🗆	
Condition of covers	🗆	🗆	🗆	
Hydraulic system leak-tightness Hydraulic oil filling level Hydraulic line conditions Condition electrical lines	🗆	🗆	🗆	
Hydraulic oil filling level	🗆	🗆	🗆	
Hydraulic line conditions	🗆	🗆	🗆	
Condition electrical lines	🗆	🗆	🗆	
Functional test in with vehicle	⊔		⊔	
Function of equalization of the lifting	ng rails 🗆	🗆	🗆	
*) Place a checkmark in the relevant, if a	retest is required then	check it again!		
Safety inspection done on:				
Performed by company:				
Name, address of specialist:				
Result of inspection:	□ Continue	d operation q	uestionable, re	einspection required
	□ Continued	doperationposs	ible,removede	fectsby
		encies, continu		
Character of an artist				
Signature of specialist	Operating comp	ouny signature		
If requested to take care of deficient	encies			
Deficiency removed on:			 Oper	ating company signature
(Use a new form for reinspection!)				



est step	OK	Defect Missing	Retest	Remarks
General condition of lift	🗆		🗆	
Model plate	🗆	🗆	🗆	
Quick operating manual	🗆	🗆	🗆	
Model plate	🗆	🗆	🗆	
Jonaition button "▲/▼" + Main switch	า ⊔	🏻	⊔	
Condition at the "Ralance" "Unlock" h	outtons \square			
Condition / function display	🗆	🗆	🗆 💳	
Condition / function display	🗆	🗆	🗆 💳	
Rridaina switch trinction	11		1 1	
Condition / function lifting arm block nterac. function Safety system Function ease of the lifting arr	🗆	🗆	🗆 💳	
nterac. function Safety system	🗆	🗆	🗆 💳	
Function ease of travel of the lifting arr	m 🗆			
Condition of the lifting arm / elastomer of Carrier plate fuse	verlav 🗆			
Carrier plate fuse	🗆			
Securing the bolts				
Condition of bolts and bearing seating	= 			
Condition of weld seams	1 1	1 1		
and hearing construction (deformations a	cracks) \square	Π	<u>-</u>	
-astenina screw torque			·······	
oad bearing construction (deformations, of astening screw torque			······· ¦	
Unit condition	□			
Piston rods surface condition				
Condition of covers				
Judgaulic system look tightness				
Hydraulic system leak-tightness				
hydraulia lina aanditians				
Tydraulic line conditions				
Functional test lift with vehicle				
-unclional lesi iii wiin venicie				
function of equalization of the lifting ro	الــــــــــــــــــــــــــــــــ	⊔	⊔	
) Place a checkmark in the relevant, if a retest	is required then	check it again!		
Safety inspection done on:				
Performed by company:				
Name, address of specialist:				
	□ Continue	d operation a	uestionable re	einspection required
toson of hispoonorn		doperationposs		
				iecisby
	□ No deficie	encies, continu	de lo operare	
	0 "	. ,		
	Operating comp	oany signature		
f requested to take care of deficiencie	e s			
Deficiency removed on:				ating company signature
			Upero	uina company sianature



Test step	OK	Defect Missing	Retest	Remarks
General condition of lift	🗆			
Model plate Quick operating manual Warning label	🗆			
Quick operating manual	🗆		🗆 💳	
Warning label	🗖			
Condition button " \blacktriangle / \blacktriangledown " + Main switc	n II	11		
Condition / function display			<u> </u>	
Operating boxes condition			<u></u>	
Condition of the "Balance" "Unlock" of Condition / function display			<u> </u>	
Condition / function lifting arm block			<u></u>	
Interac function Safety system		Π	<u> </u>	
Function ease of travel of the lifting ar	m 🗆	Π	<u> </u>	
Condition of the lifting arm / elastomer	overlav □	Π	📙	
Carrier plate fuse				
Condition of the lifting arm / elastomer of Carrier plate fuse				
Condition of bolts and bearing seating	 ¬ □			
Condition of weld seams	y □			
Load boaring construction (deformations	□			
Eastoning construction (deformations,	Clucks) 🗆			
Load bearing construction (deformations, Fastening screw torque				
Unit condition				
Piston rods surface condition	📙			
Condition of onlors				
Hydraulic system leak-tightness				
Hydraulia ail filia a laval	📙			
Hydraulia line conditions	📙			
Hydraulic line conditions	⊣			
Condition electrical lines	📙			
Functional test iiit with vehicle	🗀		⊔	
Function of equalization of the lifting re	alis ⊔	⊔	⊔	
*) Place a checkmark in the relevant, if a retes	t is required then	check it again!		
Safety inspection done on:				
Performed by company:				
Name, address of specialist:				
Result of inspection:	□ Continue	d operation a	uestionable re	einspection required
Result of Inspection.			•	
			ible,removede	iecisby
	□ No deficie	encies, contini	ue to operate	
Signature of specialist	Operating comp	oany signature		
If requested to take care of deficienci		, . 5		
ii requested to take care of deficienci	- 3			
Deficiency removed on:			Oper	ating company signature
(Use a new form for reinspection))			•	- · · · · •



Test step	OK	Defect Missing	Retest	Remarks
General condition of lift	🗆	🗆	🗆	
Madal plata				
Quick operating manual	🗆			
Model plate	🗆			
Condition button "▲/▼" + Main switch.	🗖			
Condition of the "Balance" "Unlock" bu	ittons □	Π	<u> </u>	
Condition / function display			·······	
Operating hoves condition	<u></u>		······ ¦	
Condition / function display	<u></u>		······ ¦	
Condition / function lifting arm block				
Interac function Safety system				
Function aga of traval of the lifting arm				
Interac. function Safety system Function ease of travel of the lifting arm Condition of the lifting arm / elastomer ov Carrier plate fuse	l ⊔ vorlov / □			
Condition of the litting arm / elastomet ov	reliay 🗀			
Camer plate tuse		⊣		
Securing the polits		⊣		
Condition of boits and bearing seating.	∐	∐		
Condition of weld seams	∐	∐		
Securing the bolts	acks) ∐	∐	∐	
Fastening screw torque	🗆	🗆	🗆	
Fastening anchor torque	🗆	🗆	🗆	
Unit condition	🗆	🗆	🗆	
PISTON ROAS SURTACE CONGITION	11			
Condition of covers	🏻	🏻	Ц	
Hydraulic system leak-tightness Hydraulic oil filling level Hydraulic line conditions	🗆	🗆	🗆	
Hydraulic oil filling level	🗆	🗆		
Hydraulic line conditions	🗆	🗆	🗆 💳	
Condition electrical lines	🏻	🏻	Ц	
Functional test lift with vehicle	🗆			
Functional test lift with vehicle Function of equalization of the lifting rai	ls \square	Π	······ = ——	
*) Place a checkmark in the relevant, if a retest is				
Safety inspection done on:				
Performed by company:				
Name a containe as a fine a containe				
Name, address of specialist:				
Result of inspection: \Box] Continue	d operation qu	uestionable, re	einspection required
	Continued	loperation poss	ible,removede	fectsby
] No deficie	encies, continu	ue to operate	
	perating comp	pany signature		
If requested to take care of deficiencies	S			
Deficiency removed on:			Oper	ating company signature
(Use a new form for reinspection!)			Open	aning company signature



Test step	OK	Defect Missing	Retest	Remarks
General condition of lift	🗆		🗆	
Model plate Quick operating manual. Warning label				
Quick operating manual				
Warning lahel				
Condition button " ▲ /▼" + Main switch			·······	
Condition button "▲/▼" + Main switch Condition of the "Balance" "Unlock" b	ilittons []		·······	
Condition / function display	Onoris 🗀			
Condition / function display Operating boxes condition				
Pridaina switch function				
Bridging switch function				
Condition / function litting arm block	⊣	⊣		
interaction safety system	∐	∐		
Function ease of travel of the litting arr	n 🗀		Ц	
Condition of the lifting arm / elastomer o	verlay <u>⊔</u>	∐		
Condition of the lifting arm / elastomer o Carrier plate fuse	🗆	🗆	🗆	
Securing the bolts	🗆	🗆	🗆	
Condition of bolts and bearing seating	1 1			
Condition of weld seams		🔲	П	
Load bearing construction (deformations, c	cracks) 🗆	🗆	🗆	
Fastening screw torque	🗆	🗆	🗆	
Load bearing construction (deformations, or Fastening screw torque	🗆	🗆		
Unit condition	🗆	🗆	🗆 💳	
Unit condition	🗆			
Condition of covers	11			
Hydraulic system leak-tightness				
Hydraulic oil filling level			<u>- </u>	
Hydraulic oil filling level			·······	
Condition electrical lines				
Functional test lift with vehicle				
Functional lest ill with vehicle	□			
Function of equalization of the lifting ro	IIIS ⊔	⊔	⊔	
*) Place a checkmark in the relevant, if a retest	is required then	check it again!		
Safety inspection done on:				
Performed by company:				
Name, address of specialist:				
Result of inspection:	□ Continue	d operation a	uestionable, re	einspection required
	□ Continue	loperationposs	ible removede	fectsby
		encies, continu		
'		encies, comini	de 10 obeidie	
Signature of specialist	Operating comp	any sianatura		
If requested to take care of deficiencie		ouny signature		
•	73			
Deficiency removed on:			Oper	ating company signature
(Use a new form for reinspection))			2,501	3 / 3 · · - · - ·



Test step	OK	Defect Missing	Retest	Remarks
General condition of lift	🗆	🗖	🗆	
Model plate	🗆	🗆	🗆 💳	
Quick operating manual	🗆	🗆	🗆 💳	
Warning label	🗆	🗆	🗆 💳	
Condition button A/V + Main swi	ICN ⊔			
Condition at the "Balance" "Unlack	" buttons □			
Condition / function display	🗆			
Condition / function display Operating boxes condition	🗆			
Bridaina switch tunction		11		
Condition / function lifting arm bloc	k П			
Condition / function lifting arm bloc Interac. function Safety system		Π	······	
Function ease of travel of the lifting	arm \square			
Function ease of travel of the lifting Condition of the lifting arm / elastome	er overlav □			
Carrier plate fuse	л отопа, 🗀	Π	······	
Carrier plate fuse Securing the bolts			📙 ——	
Condition of bolts and bearing seat	ina 🗆			
Condition of weld seams	" 19 □			
Load bearing construction (deformation	 s cracks) □			
Eastoning construction (deformation	s, clucks) 🗀			
Load bearing construction (deformation Fastening screw torque				
Light and dition				
Unit condition	⊣			
Piston rods surface condition	⊣		닏	
Condition of covers	⊣		닏	
Hydraulic system leak-tightness	∐	∐		
Hydraulic oil filling level	∐	∐		
Hydraulic line conditions	∐	∐		
Condition electrical lines		∐		
runctional test litt with vehicle	□	🏻	⊔	
Function of equalization of the lifting	g rails 🗆	🗆	🗆	
*) Place a checkmark in the relevant, if a ret	est is required then	check it again!		
Safety inspection done on:				
Performed by company:				
Name, address of specialist:				
Result of inspection:	□ Continue	d operation qu	uestionable, re	einspection required
·			ible,removede	
		encies, continu		
		3110103, 00111111		
Signature of specialist	Operating comp	oany signature		
If requested to take care of deficien	cies			
Deficiency removed on:			Oper	ating company signature
(Use a new form for reinspection!)			2,50.	S = = 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 -



Test step	OK	Defect Missing	Retest	Remarks
General condition of lift	🗆		🗆	
Model plate Quick operating manual. Warning label				
Quick operating manual				
Warning lahel				
Condition button " ▲ /▼" + Main switch			·······	
Condition button "▲/▼" + Main switch Condition of the "Balance" "Unlock" b	ilittons []		·······	
Condition / function display	Onoris 🗀			
Condition / function display Operating boxes condition				
Pridaina switch function				
Bridging switch function				
Condition / Tunction litting arm block	⊣	⊣		
interaction safety system	∐	∐		
Function ease of travel of the litting arr	n 🗀		Ц	
Condition of the lifting arm / elastomer o	verlay <u>⊔</u>	∐		
Condition of the lifting arm / elastomer o Carrier plate fuse	🗆	🗆	🗆	
Securing the bolts	🗆	🗆	🗆	
Condition of bolts and bearing seating	1 1			
Condition of weld seams		🔲	П	
Load bearing construction (deformations, c	cracks) 🗆	🗆	🗆	
Fastening screw torque	🗆	🗆	🗆	
Load bearing construction (deformations, or Fastening screw torque	🗆	🗆		
Unit condition	🗆	🗆	🗆 💳	
Unit condition	🗆			
Condition of covers	11			
Hydraulic system leak-tightness				
Hydraulic oil filling level			<u>- </u>	
Hydraulic oil filling level			·······	
Condition electrical lines				
Functional test lift with vehicle				
Functional lest ill with vehicle	□			
Function of equalization of the lifting ro	IIIS ⊔	⊔	⊔	
*) Place a checkmark in the relevant, if a retest	is required then	check it again!		
Safety inspection done on:				
Performed by company:				
Name, address of specialist:				
Result of inspection:	□ Continue	d operation a	uestionable, re	einspection required
	□ Continue	loperationposs	ible removede	fectsby
		encies, continu		
'		encies, comini	de 10 obeidie	
Signature of specialist	Operating comp	any sianatura		
If requested to take care of deficiencie		ouny signature		
•	73			
Deficiency removed on:			Oper	ating company signature
(Use a new form for reinspection))			2,501	3 / 3 · · - · - ·



Test step	OK	Defect Missing	Retest	Remarks
General condition of lift	🗆		🗆	
Model plate Quick operating manual Warning label	🗆	🗆	🗆 💳	
Quick operating manual	🗆	🗆	🗆 💳	
Warning label	🗆	🗆	🗆 💳	
$(\cap \cap$	וו חי	I I		
Condition of the "Balance" "Unlock"	buttons 🗆			
Condition / function display	🗆			
Condition of the "Balance" "Unlock" Condition / function display Operating boxes condition				
Bridging switch function				
Condition / function lifting arm block.				
Interac function Safety system				
Function ease of travel of the lifting a	 rm □	Π	······ – – – – – – – – – – – – – – – –	
Condition of the lifting arm / elastomer	overlav 🗆	Π	······ – – – – – – – – – – – – – – – –	
Carrier plate fuse		Π	<u>-</u>	
Securing the holts			······ ¦ ——	
Condition of holts and hearing seating				
Condition of weld seams	9			
Load boaring construction (deformations	□			
Eastoning construction (deformations,	Clucks) \square			
Fastoning sciew loique				
Bridging switch function				
Unii Condiion	📙			
Candition of acycer	📙			
Piston rods surface condition		⊣		
Hydraulic system leak-tigntness	⊣	∐		
Hydraulic oli filling level	⊣	∐		
Hydraulic line conditions	∐	∐		
Condition electrical lines	∐	∐		
Functional test lift with vehicle	∐	∐		
Function of equalization of the lifting I	′aıls ⊔	⊔	⊔	
*) Place a checkmark in the relevant, if a rete	st is required then	check it again!		
Safety inspection done on:				
Performed by company:				
chemica by company.				
Name, address of specialist:				
Result of inspection:	- Continuo	d aparation a	unctionable re	since action required
kesuii oi irispectiori.				einspection required
		doperationposs		rectsby
	☐ No deficie	encies, continu	ue to operate	
Signature of specialist	Operating comp	oany signature		
If requested to take care of deficienc	ies			
Deficiency removed on:				ating company signature
(Use a new form for reinspection!)			Open	aming company signatore



Test step	OK	Defect Missing	Retest	Remarks
General condition of lift	🗆		🗆	
Model plate Quick operating manual. Warning label				
Quick operating manual				
Warning lahel				
Condition button " ▲ /▼" + Main switch			·······	
Condition button "▲/▼" + Main switch Condition of the "Balance" "Unlock" b	ilittons []		·······	
Condition / function display	OHOIS 🗆			
Condition / function display Operating boxes condition				
Pridaina switch function				
Bridging switch function				
Condition / function litting arm block	⊣	⊣		
interaction safety system	∐	∐		
Function ease of travel of the litting arr	n 🗀		Ц	
Condition of the lifting arm / elastomer o	verlay <u>⊔</u>	∐		
Condition of the lifting arm / elastomer o Carrier plate fuse	🗆	🗆	🗆	
Securing the bolts	🗆	🗆	🗆	
Condition of bolts and bearing seating	1 1			
Condition of weld seams		🔲	П	
Load bearing construction (deformations, c	cracks) 🗆	🗆	🗆	
Fastening screw torque	🗆	🗆	🗆	
Load bearing construction (deformations, or Fastening screw torque	🗆	🗆		
Unit condition	🗆	🗆	🗆 💳	
Unit condition	🗆			
Condition of covers	11			
Hydraulic system leak-tightness				
Hydraulic oil filling level			<u>- </u>	
Hydraulic oil filling level			·······	
Condition electrical lines				
Functional test lift with vehicle				
Functional lest ill with vehicle	□			
Function of equalization of the lifting ro	IIIS ⊔	⊔	⊔	
*) Place a checkmark in the relevant, if a retest	is required then	check it again!		
Safety inspection done on:				
Performed by company:				
Name, address of specialist:				
Result of inspection:	□ Continue	d operation a	uestionable, re	einspection required
	□ Continue	loperationposs	ible removede	fectsby
		encies, continu		
'		encies, comini	de 10 obeidie	
Signature of specialist	Operating comp	any sianatura		
If requested to take care of deficiencie		ouny signature		
•	73			
Deficiency removed on:			Oper	ating company signature
(Use a new form for reinspection))			2,501	3 / 3 · · - · - ·



Test step	OK	Defect Missing	Retest	Remarks
General condition of lift	🗆	🗖	🗆	
Model plate	🗆	🗆	🗆 💳	
Quick operating manual	🗆	🗆	🗆 💳	
Warning label	🗆	🗆	🗆 💳	
Condition button A/V + Main swi	ICN ⊔			
Condition at the "Balance" "Unlack	" buttons □			
Condition / function display	🗆			
Condition / function display Operating boxes condition	🗆			
Bridaina switch tunction		11		
Condition / function lifting arm bloc	k П			
Condition / function lifting arm bloc Interac. function Safety system		Π	······	
Function ease of travel of the lifting	arm \square		<u> </u>	
Function ease of travel of the lifting Condition of the lifting arm / elastome	er overlav □		<u> </u>	
Carrier plate fuse	л отопа, 🗀	Π	······	
Carrier plate fuse Securing the bolts			📙 ——	
Condition of bolts and bearing seat	ina 🗆			
Condition of weld seams	" 19 □			
Load bearing construction (deformation	 s cracks) □			
Eastoning construction (deformation	s, ciucksj 🗀			
Load bearing construction (deformation Fastening screw torque				
Light and dition				
Unit condition	⊣			
Piston rods surface condition	⊣		닏	
Condition of covers	⊣			
Hydraulic system leak-tightness	∐	∐		
Hydraulic oil filling level	∐	∐		
Hydraulic line conditions	∐	∐		
Condition electrical lines		∐		
runctional test litt with vehicle	□	🏻	⊔	
Function of equalization of the lifting	g rails 🗆	🗆	🗆	
*) Place a checkmark in the relevant, if a ret	est is required then	check it again!		
Safety inspection done on:				
Performed by company:				
Name, address of specialist:				
Result of inspection:	□ Continue	d operation qu	uestionable, re	einspection required
·			ible,removede	
		encies, continu		
		3110103, 00111111		
Signature of specialist	Operating comp	oany signature		
If requested to take care of deficien	cies			
Deficiency removed on:			Oper	ating company signature
(Use a new form for reinspection!)			2,50.	S = = 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 -



Test step	OK	Defect Missing	Retest	Remarks
General condition of lift	🗆			
Model plate Quick operating manual Warning label	🗆			
Quick operating manual	🗆		🗆 💳	
Warning label	🗖			
Condition button " \blacktriangle / \blacktriangledown " + Main switc	n II	11		
Condition / function display			<u> </u>	
Operating boxes condition			<u></u>	
Condition of the "Balance" "Unlock" of Condition / function display			<u> </u>	
Condition / function lifting arm block			<u></u>	
Interac function Safety system		Π	<u> </u>	
Function ease of travel of the lifting ar	m 🗆	Π	<u> </u>	
Condition of the lifting arm / elastomer	overlav □	Π	📙	
Carrier plate fuse				
Condition of the lifting arm / elastomer of Carrier plate fuse				
Condition of bolts and bearing seating	 ¬ □			
Condition of weld seams	y □			
Load boaring construction (deformations	□			
Eastoning construction (deformations,	Clucks) 🗆			
Load bearing construction (deformations, Fastening screw torque				
Unit condition				
Piston rods surface condition	📙			
Condition of onlors				
Hydraulic system leak-tightness				
Hydraulia ail filia a laval	📙			
Hydraulia line conditions	📙			
Hydraulic line conditions	├			
Condition electrical lines	📙			
Functional test iiit with vehicle	🗀		⊔	
Function of equalization of the lifting re	alis ⊔	⊔	⊔	
*) Place a checkmark in the relevant, if a retes	t is required then	check it again!		
Safety inspection done on:				
Performed by company:				
Name, address of specialist:				
Result of inspection:	□ Continue	d operation a	uestionable re	einspection required
Result of Inspection.			•	
			ible,removede	iecisby
	□ No deficie	encies, contini	ue to operate	
Signature of specialist	Operating comp	oany signature		
If requested to take care of deficienci		, . 5		
ii requested to take care of deficienci	- 3			
Deficiency removed on:			Oper	ating company signature
(Use a new form for reinspection))			•	- · · · · •



9.3 Exceptional safety inspection

Test step	OK	Defect Missing	Retest	Remarks
General condition of lift	🗆		🗆	
Model plate Quick operating manual Warning label	🗆	🗆	🗆 💳	
Quick operating manual	🗆	🗆	🗆 💳	
Warning label	🗆	🗆	🗆 💳	
$(\cap \cap$	וו חי	I I		
Condition of the "Balance" "Unlock"	buttons 🗆			
Condition / function display	🗆			
Condition of the "Balance" "Unlock" Condition / function display Operating boxes condition				
Bridging switch function				
Condition / function lifting arm block.				
Interac function Safety system				
Function ease of travel of the lifting a	 rm □	Π	······	
Condition of the lifting arm / elastomer	overlav 🗆	Π	······	
Carrier plate fuse		Π	<u>-</u>	
Securing the holts			······ ¦ ——	
Condition of holts and hearing seating				
Condition of weld seams	9			
Load boaring construction (deformations	□			
Eastoning construction (deformations,	Clucks) \square			
Fastoning sciew loique				
Bridging switch function				
Unii Condiion	📙			
Candition of acycer	📙			
Piston rods surface condition		⊣		
Hydraulic system leak-tigntness	⊣	∐		
Hydraulic oli filling level	⊣	∐		
Hydraulic line conditions	∐	∐		
Condition electrical lines	∐	∐		
Functional test lift with vehicle	∐	∐		
Function of equalization of the lifting I	′aıls ⊔	⊔	⊔	
*) Place a checkmark in the relevant, if a rete	st is required then	check it again!		
Safety inspection done on:				
Performed by company:				
chemica by company.				
Name, address of specialist:				
Result of inspection:	- Continuo	d aparation a	unctionable re	since action required
kesuii oi irispectiori.				einspection required
		doperationposs		rectsby
	☐ No deficie	encies, continu	ue to operate	
Signature of specialist	Operating comp	oany signature		
If requested to take care of deficienc	ies			
Deficiency removed on:				ating company signature
(Use a new form for reinspection!)			Open	aming company signatore




Spare parts list

POWER LIFT HDL 15000 POWER LIFT HDL 18000






Column complete



1	265HDL01758_BG	DOWNPIPE	18 ELEKTROKASTEN
2	265HDL02050	PIPE	19 265HDL02712 ADAPTER PLATE
3	265HDL02053	ROD	20 265HDL05219 MOUNTING PANEL
4	265HDL05503	LIFTING COLUMN	21 265HDL01766 BLOCK COVER
5	265HDL26400	LIFT RAILS WITH LIFTING ARMS	22 265HDL05218 POWER CHAIN GUIDE
6	265HDL01750	ASSEMBLY UNIT BLOCK	23 ZS15_01_L10RB3_8 STRAIGHT SCREW IN FITTING
7	265HDL01755_BG	P-PIPE TO THE UNIT	24 175RGK05074 HOLDER
8	265HDL01762_BG	P-PIPE TO THE CYLINDER	25 265HDL01032 HOOD
9	265HDL01756_BG	T-PIPE TO THE UNIT	26 RO6X1_5X2085 HYDRAULIC PIPE
10	265HDL05050	CYLINDER HOLDER	27 265HDL05214 CABLE COVER BOTTOM
		WELDED PART	28 9SEM05X006ZN FLANGED BUTTON
11	92353-EL6	STRAIGHT SCREW FITTING	HEAD SCREW
12	9125_1-A8_4	WASHER	29 265HDL09013 COLUMN COVER TOP
13	93901-L8A-G1_4	STRAIGHT SCREW-IN SOCKET	30 9933M8X12ZN HEXAGONAL SCREW
14	93901-L6A-G1_8	SUPPORTS	31 175RGK01016 SIDE COVERS
15	9912-M5X10	CYLINDER SCREW	32 240SLK01400 SPX UNIT USA
16	9912-M8X16	CYLINDER SCREW	33 232SL05070 RISER
17	9912-M8X20	CYLINDER SCREW	




Cylinder assy.






SPX Unit USA





Block Mounting Assembly



1 99-540-11-00-5

CONTROL BLOCK

WHEEL GRIPPER

WASHER

2 91125_1-A8_4 3 93901-L8A-G1_4

STRAIGHT SCREW-IN SOCKET

4 93901-L10A-G4_4

265HDL01754

9933M8X12ZN

7 93901-L06-G1_4

BLOCK HOLDER


SUPPORTS

HEXAGONAL SCREW

SUPPORTS




Lift rails with lifting arms



1 2 3	265HDL06403	SCREW ON PLATE LIFT RAILS LIFTING ARM FIXTURE COMPLETE	8 9 10 11	265HDL06442 SPACER BAR RO12X1K5X400 CABLE PIPE LR211KDDUAH09 ROLLER LR5307KDD ROLLER
	RO12X1K5X52 9S933M24X80 265HDL06432 265HDL06436	9S933M24X80	12 13 14 15	9125_1-A5_3 WASHER 250T\$APH08126 HOSE COVER 265HDL06445 U-PROFILE 9912-M5X20 CYLINDER SCREW




Hood






Lifting arm fixture complete



- 1 250TSAPH28079 BOLTS ASSY.
- 2 250TSAPH28001 LIFTING ARM
- 3 250TSAPH28002 LIFTING ARM
- 4 9912-M5X30 CYLINDER SCREW
- 5 250TSAPH08084 BOLT RETAINER
- 6 250TSAPH08104 LIFTING ARM FIXTURE COMPLETE
- 7 250TSAPH08088 TOOTHED LOCK WASHER



Lifting arm fixture complete



1 280HDL08079	BOLTS ASSY.
---------------	-------------

- 2 280HDL08001 LIFTING ARM 1
- 3 280HDL08002 LIFTING ARM 2

- 4 5 250TSAPH08084 BOLT RETAINER
- 280HDL08094 LIFTING ARM FIXTURE COMPLETE
- 6 250TSAPH08088 TOOTHED LOCK WASHER 1

Dealer address/phone:	
.,	



Nussbaum Automotive Solutions, LP • 1932 Jordache Court • Gastonia, NC 28052 www.nussbaum-usa.com • E-Mail: warranty@nussbaum-usa.com

Fax: 1-704-864-2476

Service Hotline International: +49 180-5 288 911

OPI-POWER LIFT HDL 15000 - HDL 18000-V1.0-EN_012020 - Artikelnummer: 975539